



# ZXA10 F660

## Optical Network Terminal

# Maintenance Management Manual

---

V1.0

Jamii Telecommunications Limited  
<http://jamii.co.ke>  
E-mail: [jtlsupport@jtl.co.ke](mailto:jtlsupport@jtl.co.ke)  
Tel pilot: +254 203975100  
Saf pilot: +254 711054110

## **LEGAL INFORMATION**

Copyright © 2010 ZTE CORPORATION.

The contents of this document are protected by copyright laws and international treaties. Any reproduction or distribution of this document or any portion of this document, in any form by any means, without the prior written consent of JTL CORPORATION is prohibited. Additionally, the contents of this document are protected by contractual confidentiality obligations.

All company, brand and product names are trade or service marks, or registered trade or service marks, of JTL CORPORATION or of their respective owners.

This document is provided "as is", and all express, implied, or statutory warranties, representations or conditions are disclaimed, including without limitation any implied warranty of merchantability, fitness for a particular purpose, title or non-infringement. JTL CORPORATION and its licensors shall not be liable for damages resulting from the use of or reliance on the information contained herein.

JTL CORPORATION or its licensors may have current or pending intellectual property rights or applications covering the subject matter of this document. Except as expressly provided in any written license between JTL CORPORATION and its licensee, the user of this document shall not acquire any license to the subject matter herein.

The ultimate right to interpret this product resides in JTL CORPORATION.

## **Revision History**

<b>Revision No.</b>	<b>Revision Date</b>	<b>Revision Reason</b>
1.0	2011-05-17	First Edition

Serial Number: SJ-20110517135211-002

Publishing Date: 2011-05-17 (R1.0)

# Contents

---

<b>Chapter 1 Overview .....</b>	<b>1-1</b>
1.1 Safety Precautions .....	1-1
1.2 Packing List .....	1-2
1.3 Features and Specifications .....	1-3
1.4 Product Appearance.....	1-4
1.5 System Requirements .....	1-6
1.6 System Application Environment .....	1-7
<b>Chapter 2 Configuration Preparation .....</b>	<b>2-1</b>
2.1 Preliminary Setup.....	2-1
2.2 Configuring TCP/IP .....	2-1
2.3 Logging In to the Device .....	2-6
<b>Chapter 3 Device Status .....</b>	<b>3-1</b>
3.1 Device Information .....	3-1
3.2 Network Connection Information.....	3-2
3.3 User Interface Information.....	3-3
3.3.1 WLAN Interface Information .....	3-3
3.3.2 Ethernet Interface Information .....	3-4
3.3.3 VoIP Status Information .....	3-5
<b>Chapter 4 Network Configuration .....</b>	<b>4-1</b>
4.1 Configuring WAN Connection.....	4-1
4.2 WLAN Configuration.....	4-5
4.2.1 Configuring Basic WLAN Parameters .....	4-5
4.2.2 Configuring Multi-SSID Parameters .....	4-7
4.2.3 Configuring Security Properties .....	4-8
4.2.4 Viewing Associated Devices .....	4-12
4.3 Address Management Configuration.....	4-13
4.3.1 Configuring DHCP Server .....	4-13
4.3.2 Configuring DHCP Binding.....	4-14
4.3.3 Configuring Specific Address Range.....	4-15
4.4 Route Management Configuration .....	4-16
4.4.1 Configuring Default Gateway.....	4-17

4.4.2 Configuring Static Routing .....	4-18
<b>Chapter 5 Security Configuration .....</b>	<b>5-1</b>
5.1 Configuring Firewall.....	5-1
5.2 Configuring IP Filter.....	5-2
5.3 Configuring URL Filter .....	5-5
5.4 Configuring DMZ Host .....	5-7
5.5 Configuring Port Forwarding .....	5-8
<b>Chapter 6 Service Configuration.....</b>	<b>6-1</b>
6.1 SIP VoIP Service Configuration .....	6-1
6.1.1 Configuring VoIP WAN Connection.....	6-1
6.1.2 Configuring SIP.....	6-2
6.1.3 Configuring SIP Accounts .....	6-4
6.1.4 Configuring VoIP Advanced Parameters .....	6-5
6.1.5 Configuring VoIP Media Parameters .....	6-7
6.1.6 Configuring Fax.....	6-8
6.2 Configuring DDNS.....	6-9
6.3 Configuring UPnP .....	6-11
6.4 DNS Configuration .....	6-13
6.4.1 Configuring Domain Name.....	6-13
6.4.2 Configuring Host Name .....	6-14
6.5 QoS Configuration.....	6-15
6.5.1 Configuring Basic QoS Parameters .....	6-16
6.5.2 Configuring QoS Rule.....	6-18
6.5.3 Configuring QoS Rule Type.....	6-19
6.5.4 Configuring QoS Local Application .....	6-21
6.5.5 Configuring QoS Queue Management .....	6-22
6.5.6 Configuring QoS Ingress Rate Limit.....	6-23
6.6 Configuring SNTP Client.....	6-25
6.7 IGMP Configuration.....	6-27
6.7.1 Configuring Basic IGMP Parameters .....	6-27
6.7.2 Configuring Multicast VLAN .....	6-29
6.7.3 Configuring Multicast MAC Limit.....	6-31
6.7.4 Configuring MVLAN Tag Strip.....	6-33
6.8 Configuring FTP Application.....	6-34
<b>Chapter 7 Device Management .....</b>	<b>7-1</b>
7.1 TR-069 Configuration .....	7-1
7.1.1 Configuring Basic TR-069 Parameters.....	7-1

7.1.2 Importing TR-069 Certificate .....	7-3
7.2 User Management.....	7-4
7.3 Device Management.....	7-5
7.3.1 System Management.....	7-5
7.3.2 Software Upgrade .....	7-6
7.3.3 Configuration Management.....	7-8
7.4 Log Management .....	7-9
7.5 Ping Diagnosis.....	7-10
<b>Appendix A FAQ .....</b>	<b>A -1</b>
A .1 FAQ .....	A -1
<b>Index .....</b>	<b>I</b>
<b>Glossary .....</b>	<b>III</b>



# Chapter 1

## Overview

---

### Table of Contents

Safety Precautions .....	1-1
Packing List.....	1-2
Features and Specifications .....	1-3
Product Appearance.....	1-4
System Requirements .....	1-6
System Application Environment .....	1-7

## 1.1 Safety Precautions

### Usage Cautions

- Read all the safety cautions carefully before using the device.
- Only use the accessories included in the package, such as power supply adapter and battery.
- The power supply voltage must meet the requirements of the device input voltage (The voltage fluctuation range is less than 10%).
- Keep the power plug clean and dry to prevent any risk of electronic shock or other danger.
- Make sure to disconnect all the cables during a lightning storm to prevent the device from damage.
- Power off and unplug the power plug when the device is not in use for a long time.
- Do not attempt to open the covers of the device. It is dangerous to do so when the device is powered ON.
- Do not directly stare at the optical interface to prevent the eyes from being hurt.
- Power off and stop using the device under the following conditions: abnormal sound, smoke, and strange smell. Contact the service provider for maintenance if the device is faulty.



#### Note

The users should read the usage cautions above carefully and will be responsible for any incident resulted from the violation of the cautions above.

---

### Environment Requirements

- Ensure the proper ventilation to the device. Place the device out of the direct sunlight.
- Keep the device ventilated and dry. Never spill any liquid on the device.
- Do not place any object on the device, in case it gets deformed and damaged.
- Do not place the device near any source of heat or water.
- Keep the device away from any household appliances with strong magnetic or electric fields, such as microwave oven and refrigerator.

### Cleaning Requirements

- Before the cleaning, power off the device, and unplug all the cables connected to the device, such as power cable, optical fiber, and Ethernet cable.
- Do not use any liquid or spray to clean the device. Use the soft dry cloth.

### Environment Protection

- Do not dispose the device or battery improperly.
- Observe the local regulations about the equipment disposal or treatment.

## 1.2 Packing List

After opening the ZXA10 F660 packing box, make sure that it contains the following components, as listed in [Table 1](#).

Table 1 Packing List

Component Name	Count	Image
ZXA10 F660 host	1	
Power adapter	1	
Power cable	1	

Component Name	Count	Image
RJ-45 network cable	1	
RJ-11 telephone cable	2	

One *ZXA10 F660 (V1.0) Optical Network Terminal User Manual* is delivered with the product.

If any of the components are incorrect, lost, or damaged, contact the product agency. If you want to change the product, keep the packing box and components.

## 1.3 Features and Specifications

### System Features

The ZXA10 F660 has the following features:

- MAC cache: 4K
- Multicast services: 1024 multicast groups
- VLAN range: 1–4095
- GEM ports: 32
- T-CONTs: 8

### Interface Features

The interface features are as follows:

- GPON interface: in compliance with the PON standard, SC/APC, and ITU G.984.1–G.984.5 standards
- Ethernet interface: 10/100/1000 Mbps GE interfaces (RJ-45), in compliance with IEEE 802.3 standards
- POTS interface: RJ-11
- WLAN interface: in compliance with the IEEE 802.11n standard with built-in antenna

### Technical Features

The ZXA10 F660 implements the following functions:

- For data access, the ZXA10 F660 implements L2 data switching and forwarding.

By working with relevant network devices through signaling protocols such as H.248 and SIP, the ZXA10 F660 implements the IP voice function.

- The ZXA10 F660 provides the security, QoS, and network management functions, such as multi-level authentication based on devices, users, and services.

It supports data channel encryption, implementation of QoS requirements matching the local devices and network according to services with different requirements, and network management based in various management modes.

## Product Specifications

The ZXA10 F660 specifications are as follows:

- Rated current: 1.3 A
- Rated voltage: 12 V DC
- Operating temperature:  $-5^{\circ}\text{C}$  to  $50^{\circ}\text{C}$
- Operating humidity: 5%–95%
- Dimensions: 260 mm × 50 mm × 185 mm (Width × Height × Depth)

# 1.4 Product Appearance

## Front Panel

Figure 1 shows the front panel of the ZXA10 F660.

Figure 1 Front Panel



Table 2 lists LEDs on the front panel.

Table 2 Front Panel LEDs

LED	Status	Description
PON	Solid green	The ONT GPON is registered and the link is activated.
	OFF	The ONT is not discovered and registered.
	Flashing	The ONT is trying to be registered or set up the connection.
LOS	Solid red	The ONU receives the optical power abnormally.
	OFF	The ONU receives the optical power normally.
	Flashing	The WAN connection is abnormal. The ONU fails to acquire the IP address.

LED	Status	Description
WLAN	Solid green	The WLAN function is enabled.
	OFF	The device is not powered ON or the wireless interface is disabled.
	Flashing	Data is being transmitted.
USB	Solid green	The USB interface is connected but no data is going through.
	OFF	The USB interface is not connected to a storage device.
	Flashing	There is data going through the USB interface.
POTS1–POTS2	Solid green	The device is registered on the SS, but no data is being transmitted.
	OFF	The device is not powered ON or fails to be registered on the SS.
	Flashing	Data is being transmitted.
LAN1–LAN4	Solid green	The network interface is connected, but no data is being transmitted.
	OFF	The device is not powered ON or the network interface is not connected with a network device.
	Flashing	Data is being transmitted.
Power indicator	Solid blue	The device is powered ON normally.
	OFF	The device is not powered ON.

## Back Panel

Figure 2 shows the back panel of the ZXA10 F660.

Figure 2 Back Panel



Table 3 lists the interfaces and buttons on the back panel.


Table 3 Interfaces and Buttons on the Back Panel

Interface/Button	Description
LAN1–LAN4	RJ-45 LAN interface, connecting to the local network through the RJ-45 network cable
POTS1–POTS2	RJ-11 telephone interface, connecting to the telephone through the RJ-11 telephone cable
USB	USB interface, connecting to a storage device that has a USB interface
UPS	Secondary power monitoring interface
POWER	Power socket, connecting to the power adapter, 12 V DC
WLAN	WLAN button, to enable or disable WLAN
RESET	When the device is powered ON, press the button for more than five seconds to restore the factory default settings.

### Side Panel

The side panel has an SC/APC single-mode fiber interface, implementing the services provided by the ISP in PON access mode. It connects to the GPON interface of the ZXA10 F660 through an SC/APC single-mode fiber. [Figure 3](#) shows the side panel.

Figure 3 Side Panel



## 1.5 System Requirements

The ZXA10 F660 system requirements are as follows:

- An ISP is needed so that the device can access the services provided by the ISP in PON access mode.
- A computer that is installed with a 10 Mbps/100 Mbps/1000 Mbps Ethernet card is needed.

- If necessary, create a medium and small LAN by adding Ethernet hubs and cables.
- To use wireless access, an 802.11g/b wireless network card or a built-in 802.11g/b wireless network card is required.
- The computer that accesses the network should be installed with Windows 98/Me/2000/NT/XP/Vista/7 or Linux, network card driver program, and TCP/IP protocol, and its network settings should be correct.
- A computer in the LAN is installed with a Web browser, such as Microsoft Internet Explorer 6.0 or later version, Netscape Communicator 4.0 or later version.

## 1.6 System Application Environment

The ZXA10 F660 is an indoor device of ZTE series optical network terminal equipment. It works with the PON device to implement the FTTH application.

With the use of multiple user interfaces, hub, or Ethernet switch, the ZXA10 F660 can implement the FTTO/B application.

Figure 4 shows the ZXA10 F660 application environment.


Figure 4 System Application Environment



As an indoor device, the ZXA10 F660 can be put on the desk with the base or hung on the wall without the base.

Figure 5 shows the ZXA10 F660 on a wall.

Figure 5 Wall-Mount



# Chapter 2

## Configuration Preparation

---

### Table of Contents

Preliminary Setup .....	2-1
Configuring TCP/IP .....	2-1
Logging In to the Device .....	2-6

## 2.1 Preliminary Setup

Generally, the ISP has already configured the device. The user can directly use it after hardware connection. However, the user may need to configure the device in some special situations. The user must confirm the following preliminary setups:

- Use one crossover or straight-through Ethernet cable to connect a computer to the device.
- Check the TCP/IP settings of the computer.
- Disable any running firewall or security software.
- Disable the proxy server of the Internet Explorer.
- Consult the ISP if some data from the ISP is needed.

## 2.2 Configuring TCP/IP

### ShortDescription

Perform this procedure to configure TCP/IP of a computer connected to the ZXA10 F660.

### Context

This instance takes Windows XP as an example.

The default network settings for the ZXA10 F660 are as follows:


- IP address: 192.168.1.1
- Subnet mask: 255.255.255.0
- Default gateway: 192.168.1.1

To configure TCP/IP, perform the following steps:

## Steps


1. Choose **Start> Settings> Network Connections** to open the **Network Connections** window.
2. Double-click **Local Area Connection** to open the **Local Area Connection Status** dialog box, as shown in [Figure 6](#).

Figure 6 Local Area Connection Status




3. Click **Properties** in the **General** tab to open the **Local Area Connection Properties** dialog box.
4. Select **Internet Protocol (TCP/IP)**, as shown in [Figure 7](#).

Figure 7 Local Area Connection Properties



5. Click **Properties** to open the **Internet Protocol (TCP/IP) Properties** dialog box. Select **Use the following IP address** and specify the **IP address**, **Subnet mask**, and **Default gateway**. For example, you can set the **IP address** to 192.168.1.7, **Subnet mask** to 255.255.255.0, and **Default gateway** to 192.168.1.1, as shown in [Figure 8](#).

Figure 8 Specifying the IP address in the Internet Protocol (TCP/IP) Properties

**Note**

The IP address shall be in the same network segment as LAN port address of the device, which means the IP address you type in should be “192.168.1.x” (x can be any value from 2 to 254).

6. Click **OK** to save your settings.

**Note**

If you are accessing the WEB page of the device for the first time, please configure the device as you are told.

– End of Steps –

**Follow-Up Action**

1. Choose **Start> Run** to open the **Run** dialog box.

2. Type `CMD` in the **Open** text box, and click **OK**.
3. Type `ping 192.168.1.1` in the pop-up window and press **Enter** to carry out the ping command.
  - If the command window displays the messages, as shown in [Figure 9](#), it indicates that the communication between your PC and the device is normal and you are able to access the Internet now.

Figure 9 Successful Ping Message

```

C:\WINDOWS\system32\cmd.exe
Microsoft Windows XP [Version 5.1.26001]
(C) Copyright 1985-2001 Microsoft Corp.

C:\Documents and Settings\zte>ping 192.168.1.1

Pinging 192.168.1.1 with 32 bytes of data:

Reply from 192.168.1.1: bytes=32 time<1ms TTL=64

Ping statistics for 192.168.1.1:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
    Approximate round trip times in milli-seconds:
        Minimum = 0ms, Maximum = 1ms, Average = 0ms

C:\Documents and Settings\zte>_
    
```

- If the command window displays the messages, as shown in [Figure 10](#), it indicates that the communication between your PC and the device fails.

Figure 10 Failed Ping Message

```

D:\WINDOWS\system32\cmd.exe
Microsoft Windows XP [Version 5.1.26001]
(C) Copyright 1985-2001 Microsoft Corp.

C:\Documents and Settings\zte>ping 192.168.1.1

Pinging 192.168.1.1 with 32 bytes of data:

Request timed out.
Request timed out.
Request timed out.
Request timed out.

Ping statistics for 192.168.1.1:
    Packets: Sent = 4, Received = 0, Lost = 4 (100% loss),

C:\Documents and Settings\zte>_
    
```

If the communication between your PC and the device fails, ensure the following items:

- The Ethernet cable between the device and your PC has been connected properly.
- The driver of your network adapter has been installed properly.

- The TCP/IP setting has been configured correctly on your PC.

If the ZXA10 F660 IP address is 192.168.1.1, the IP address of the computer must be from 192.168.1.2 to 192.168.1.254. The subnet mask must be 255.255.255.0 and the default gateway must be 192.168.1.1.

## 2.3 Logging In to the Device

### ShortDescription

Perform this procedure to log in to the device.

### Pre-requisites

The device is properly connected and the computer is correctly configured.

### Context

To log in to the device, perform the following steps:

### Steps

1. Open the Internet Explorer. Enter `http://192.168.1.1` (default IP address of the device) on the address bar and press **Enter**. The login dialog box is displayed, as shown in [Figure 11](#).

Figure 11 Login



2. Enter the **Username** and **Password** (by default, both are `admin` ). Click **Login**.

– End of Steps –

### Result

Logging in to the device is successful.

# Chapter 3

## Device Status

### Table of Contents

Device Information .....	3-1
Network Connection Information.....	3-2
User Interface Information.....	3-3

## 3.1 Device Information

On the Web interface of the device, click the **Status** tab. By default, the **Device Information** is selected. The right pane displays the device type, serial number, and version information, and registration password, as shown in [Figure 12](#).

Figure 12 Device Information



Copyright © 2008 ZTE Corporation. All rights reserved.

Table 4 lists the parameters for the device information.

Table 4 Device Information Parameters

Parameter	Description
Model	Device type
Serial Number	Device serial number
Hardware Version	Hardware version number
Software Version	Software version number


Parameter	Description
Boot Loader Version	Boot version number
PON Serial Number	PON serial number
Password	Password used by the ONU registration on the OLT

## 3.2 Network Connection Information

On the **Status** tab, select **Network Interface**. By default, the **WAN Connection** sub-node is selected. The right pane displays the WAN connection information, as shown in [Figure 13](#).

Click **Refresh** to view the latest information.

Figure 13 WAN Connection



The screenshot shows the ZTE management interface for the ZXA10 F660. The 'Network Interface' section is active, and the 'WAN Connection' sub-tab is selected. The interface displays the following parameters:

omci1	Static
VLAN ID	3000
NAT	Enabled
IP	10.40.110.95/255.255.255.0
DNS	
Default Gateway	10.40.110.254
Connection Status	Connected

A 'Refresh' button is visible at the bottom right of the interface. The footer contains the text: Copyright © 2008 ZTE Corporation. All rights reserved.

[Table 5](#) lists the parameters for the network connection information.

[Table 5 Parameters for the Network Connection Information](#)

Parameter	Description
omci1	WAN connection type
VLAN ID	VLAN ID used by the WAN interface to send and receive data
NAT	Whether to enable the NAT function
IP	IP address used by ZXA10 F660
DNS	DNS used by ZXA10 F660
Default Gateway	Gateway used by ZXA10 F660
Connection Status	WAN connection status



**Note**

**OMCI1** is the WAN connection name, which is created by the OMCI interface remotely.

## 3.3 User Interface Information

This topic includes the following:

- WLAN Interface Information
- Ethernet Interface Information
- VoIP Status Information

### 3.3.1 WLAN Interface Information

On the **Status** tab, select **User Interface**. By default, **WLAN** is selected. The right pane displays the WLAN switch information, packet receiving and sending information, and authentication information, as shown in [Figure 14](#).

Click **Refresh** to view the latest information.

Figure 14 WLAN Interface Information

ZTE中兴		ZXA10   F660	
Status	Network	Security	Application
Enable Wireless RF	Enabled		
Channel	11		
SSID1 Enable	Enabled		
SSID1 Name	SSID1		
Authentication Type	Open System		
Encryption Type	None		
MAC Address	00:d0:d0:13:14:56		
Packets Received/Bytes Received	227/24099		
Packets Sent/Bytes Sent	22400/972563		
Error Packets Received	0		
Error Packets Sent	0		
Discarded Receiving Packets	0		
Discarded Sending Packets	0		
SSID2 Enable	Disabled		
SSID3 Enable	Disabled		
SSID4 Enable	Disabled		

Refresh

Copyright © 2008 ZTE Corporation. All rights reserved.

[Table 6](#) lists the parameters for the WLAN interface information.

Table 6 Parameters for the WLAN Interface Information

Parameter	Description
Enable Wireless RF	Whether to enable the wireless RF
Channel	Channel
SSID1 Enable	Whether to enable the wireless network SSID1
SSID1 Name	SSID1 name, which identifies the wireless network service area
Authentication Type	Authentication mode
Encryption Type	Encryption mode
MAC Address	MAC address
Packets Received/Bytes Received	Number of received packets or bytes
Packets Sent/Bytes Sent	Number of sent packets or bytes
Error Packets Received	Error packets received
Error Packets Sent	Error packets sent
Discarded Receiving Packets	Discarded receiving packets
Discarded Sending Packets	Discarded sending packets

### 3.3.2 Ethernet Interface Information

On the **Status** tab, select **User Interface**. Select **Ethernet**. The right pane displays the packet receiving and sending information on the Ethernet interface, as shown in [Figure 15](#).

Click **Refresh** to view the latest information.

Figure 15 Ethernet Interface Information

Ethernet Port	LAN1
Packets Received/Bytes Received	382/31377
Packets Sent/Bytes Sent	3495/223680
Error Frames	0

Ethernet Port	LAN2
Packets Received/Bytes Received	0/0
Packets Sent/Bytes Sent	0/0
Error Frames	0

Ethernet Port	LAN3
Packets Received/Bytes Received	0/0
Packets Sent/Bytes Sent	0/0
Error Frames	0

Ethernet Port	LAN4
Packets Received/Bytes Received	0/0
Packets Sent/Bytes Sent	0/0
Error Frames	0

Table 7 lists the parameters for the Ethernet interface information.

Table 7 Parameters for the Ethernet Interface Information

Parameter	Description
Ethernet Port	Port name
Packets Received/Bytes Received	Number of received packets or bytes
Packets Sent/Bytes Sent	Number of sent packets or bytes
Error Frames	Ethernet error frames

### 3.3.3 VoIP Status Information

On the **Status** tab, select **User Interface**. Select **VoIP Status**. The right pane displays the VoIP status information, as shown in Figure 16.

Click **Refresh** to view the latest information.

Figure 16 VoIP Status Information



Table 8 lists the parameters for the VoIP status information.

Table 8 Parameters for the VoIP Status Information

Parameter	Description
SIP Account Username	Telephone number
SIP Register Status	Registration status of the voice service

# Chapter 4

## Network Configuration

---

### Table of Contents

Configuring WAN Connection .....	4-1
WLAN Configuration.....	4-5
Address Management Configuration .....	4-13
Route Management Configuration.....	4-16

## 4.1 Configuring WAN Connection

### ShortDescription

Perform this procedure to configure the WAN connection.

### Pre-requisites

The user has logged in to the Web interface of the device.

### Context

To configure the WAN connection, perform the following steps:

### Steps

1. On the Web interface of the device, click the **Network** tab. By default, **WAN Connection** is selected, as shown in [Figure 17](#).

Figure 17 WAN Connection

2. The connection type can be **PPPoE**, **Static**, or **DHCP**.

a. Configure the PPPoE mode.

Select **PPPoE** for **Type**, as shown in Figure 18.

Figure 18 PPPoE Mode Configuration

Table 9 lists the parameters for the PPPoE mode configuration.

Table 9 Parameters for PPPoE Mode Configuration

Parameter	Description
Type	Connection mode
Connection Name	PPPoE connection name, automatically generated by the system
Enable NAT	Whether to enable the NAT function

Parameter	Description
Service List	Service modes supported by the system: <ul style="list-style-type: none"> <li>● Tr-069 service mode Remote maintenance and management mode</li> <li>● Internet service mode Broadband and IPTV service mode</li> <li>● VoIP service mode Voice service mode</li> </ul>
VLAN ID	VLAN ID
Username	User name, used by the device authentication on interworking
Password	Password, used by the device authentication on interworking
Authentication Type	Authentication type, the same as the authentication type for the upper-layer device
Connection Trigger	Dial-up connection mode: <ul style="list-style-type: none"> <li>● Always On</li> <li>● On Demand</li> <li>● Manual</li> </ul>
Idle Timeout	Idle time before the dial-up auto disconnection, available only in On Demand mode

b. Configure the static mode.

Select **Static** for **Type**, as shown in [Figure 19](#).

Figure 19 Static Mode Configuration

The screenshot shows the ZTE ZXN10 F660 web interface. The top navigation bar includes 'Status', 'Network', 'Security', 'Application', 'Administration', and 'Logout'. The left sidebar has 'WAN Connection' selected, with sub-options for 'WLAN', 'Address Management', and 'Routing Management'. The main configuration area is for 'WAN Connection' and is set to 'Static' mode. The 'Type' dropdown is set to 'Static'. The 'Connection Name' is 'Create WAN Connection'. 'Enable NAT' is checked. The 'Service List' is set to 'TR069'. Below these are input fields for 'VLAN ID', 'IP Address', 'Subnet Mask', 'Default Gateway', 'DNS Server1 IP Address', 'DNS Server2 IP Address', and 'DNS Server3 IP Address'. At the bottom, there are 'Create' and 'Cancel' buttons. A copyright notice at the bottom reads: 'Copyright © 2008 ZTE Corporation. All rights reserved.'

Table 10 lists the parameters for the static mode configuration.


Table 10 Static Mode Configuration

Parameter	Description
Type	Connection mode
Connection Name	Static connection name, automatically generated by the system
Enable NAT	Whether to enable the NAT function
Service List	Service modes supported by the system: <ul style="list-style-type: none"> <li>● Tr-069 service mode Remote maintenance and management mode</li> <li>● Internet service mode Broadband and IPTV service mode</li> <li>● VoIP service mode Voice service mode</li> </ul>
VLAN ID	VLAN ID
IP Address	IP address used by ZXA10 F660
Subnet Mask	Subnet mask used by ZXA10 F660
Default Gateway	Gateway used by ZXA10 F660
DNS Server1 IP Address	IP address of DNS1 used by ZXA10 F660
DNS Server2 IP Address	IP address of DNS2 used by ZXA10 F660
DNS Server3 IP Address	IP address of DNS3 used by ZXA10 F660

- c. Configure the DHCP mode.

Select **DHCP** for **Type**, as shown in [Figure 20](#).

Figure 20 DHCP Mode Configuration



The screenshot shows the ZTE F660 web interface for DHCP mode configuration. The interface includes a navigation menu with options like WAN Connection, WLAN, Address Management, and Routing Management. The main configuration area shows the following settings:

- Type: DHCP
- Connection Name: Create WAN Connection
- Enable NAT:
- Service List: TR069
- VLAN ID: (empty field)

At the bottom, there are 'Create' and 'Cancel' buttons, and a copyright notice: Copyright © 2008 ZTE Corporation. All rights reserved.

[Table 11](#) lists the parameters for the DHCP mode configuration.

Table 11 DHCP Mode Configuration

Parameter	Description
Type	Connection mode
Connection Name	DHCP connection name, automatically generated by the system
Enable NAT	Whether to enable the NAT function
Service List	Service modes supported by the system: <ul style="list-style-type: none"> <li>● Tr-069 service mode Remote maintenance and management mode</li> <li>● Internet service mode Broadband and IPTV service mode</li> <li>● VoIP service mode Voice service mode</li> </ul>
VLAN ID	VLAN ID

- Click **Create** to finish the configuration. Click **Cancel** to cancel the configuration.

– End of Steps –

### Result

WAN connection configuration is complete.

## 4.2 WLAN Configuration

This topic includes the following:

- Configuring Basic WLAN Parameters
- Configuring Multi-SSID Parameters
- Configuring Security Properties
- Viewing Associated Devices

### 4.2.1 Configuring Basic WLAN Parameters

#### ShortDescription

Perform this procedure to configure the basic WLAN parameters.

#### Pre-requisites

The user has logged in to the Web interface of the device.

#### Context

To configure the basic WLAN parameters, perform the following steps:

## Steps

1. On the **Network** tab, select **WLAN** on the left pane. By default, the **Basic** sub-node is selected, as shown in [Figure 21](#).

Figure 21 Basic WLAN Configuration



The screenshot shows the ZTE F660 Basic WLAN Configuration interface. The left sidebar contains a tree view with 'WLAN' selected and 'Basic' sub-selected. The main configuration area includes the following parameters:

- Enable Wireless RF:
- Mode: Mixed(802.11b+802.11g)
- Country/Region: China
- Channel: Auto
- Beacon Interval: 100 ms
- Tx Rate: Auto
- Transmitting Power: 100%
- QoS Type: Disabled
- RTS Threshold: 2347
- DTIM Interval: 1
- Fragment Threshold: 2346

At the bottom of the configuration area, there are 'Submit' and 'Cancel' buttons. The footer contains the text: Copyright © 2008 ZTE Corporation. All rights reserved.

2. Configure the basic WLAN parameters, as listed in [Table 12](#).

Table 12 Basic WLAN Parameters

Parameter	Description
Enable Wireless RF	Whether to enable wireless RF
Mode	Wireless communication mode
Country/Region	Country or region name
Channel	Wireless channel number Select a proper channel according to the country code
Beacon Interval	Beacon interval
Tx Rate	Data transmission rate A low data transmission rate can enlarge the wireless communication area.
Transmitting Power	Transmission power
QoS Type	QoS priority type
RTS Threshold	RTS threshold
DTIM Interval	DTIM interval
Fragment Threshold	Fragment threshold If a packet size exceeds this threshold, the packet is divided into several fragments for transmission.

- Click **Submit** to finish the configuration. Click **Cancel** to cancel the configuration.
- End of Steps –

### Result

The basic WLAN parameters are configured.

## 4.2.2 Configuring Multi-SSID Parameters

### ShortDescription

Perform this procedure to configure multi-SSID parameters.

### Pre-requisites

The user has logged in to the Web interface of the device.

### Context

To configure multi-SSID parameters, perform the following steps:

### Steps

- On the **Network** tab, click **WLAN** on the left pane. Select **Multi-SSID Settings**, as shown in [Figure 22](#).

Figure 22 Multi-SSID Settings

The screenshot shows the ZTE ZXN10 F660 web interface. The top navigation bar includes 'Status', 'Network', 'Security', 'Application', 'Administration', and 'Logout'. The left sidebar is expanded to 'WLAN', with 'Multi-SSID Settings' selected. The main configuration area displays the following fields:

- Choose SSID:
- Hide SSID:
- Enable SSID:
- SSID Name:  (1-32 characters)

At the bottom of the configuration area, there are 'Submit' and 'Cancel' buttons. The footer contains the copyright notice: 'Copyright © 2008 ZTE Corporation. All rights reserved.'

- Configure the multi-SSID parameters as shown in [Table 13](#).

Table 13 Multi-SSID Parameters

Parameter	Description
Choose SSID	Choose the SSID that needs to be configured.
Hide SSID	Disable or enable SSID broadcast.
Enable SSID	Enable the SSID.

Parameter	Description
SSID Name	SSID name. It cannot exceed 32 characters and is case sensitive. It is used to control the WLAN access. The SSID name must match all the SSIDs of the related access nodes; otherwise, the device cannot be accessed. Up to four WLAN sub-ports are supported.

- Click **Submit** to finish the configuration. Click **Cancel** to cancel the configuration.

– End of Steps –

### Result

The multi-SSID parameters are configured.

## 4.2.3 Configuring Security Properties

### ShortDescription

Perform this procedure to configure the security properties.

### Pre-requisites

The user has logged in to the Web interface of the device.

### Context

To configure the security properties, perform the following steps:

### Steps

- On the **Network** tab, select **WLAN**, and then select **Security**, as shown in [Figure 23](#).

Figure 23 Security Properties



SSID supports four authentication modes: **Open System**, **Shared Key**, **WPA-PSK**, and **WPA2-PSK**.

- From the **Choose SSID** drop-down list, select an SSID.

- a. In **Authentication Type**, select **Open System**, and then enable **WEP Encryption** (by default, it is disabled). The **Open System** configuration information is displayed, as shown in [Figure 24](#).

Figure 24 Open System Configuration

[Table 14](#) lists the parameters for the **Open System** authentication mode.

[Table 14 Parameters for Open System Authentication Mode](#)

Parameter	Description
Choose SSID	Current SSID
Authentication Type	Current SSID authentication mode
WEP Encryption	To enable or disable WEP encryption
WEP Encryption Level	WEP encryption length <ul style="list-style-type: none"> <li>The 128-bit encryption can be a 13-bit ASCII codes or a 26-bit hexadecimal number.</li> <li>The 64-bit encryption can be a 5-bit ASCII code or a 10-bit hexadecimal number.</li> </ul> Generally, the 64-bit encryption can meet the user requirements. To enhance security, use the 128-bit encryption.
WEP Key Index	Current encryption value
WEP Key1	WEP encryption value Range: 5-bit ASCII code or 10-bit hexadecimal number
WEP Key2	WEP encryption value Range: 5-bit ASCII code or 10-bit hexadecimal number
WEP Key3	WEP encryption value Range: 5-bit ASCII code or 10-bit hexadecimal number

Parameter	Description
WEP Key4	WEP encryption value Range: 5-bit ASCII code or 10-bit hexadecimal number

- b. In **Authentication Type**, select **Shared Key**. By default, **WEP Encryption** is enabled. The **Shared Key** configuration information is displayed, as shown in [Figure 25](#).

Figure 25 Shared Key Configuration

26 hexadecimal digits or 13 ASCII chars can be entered for 128-bit WEP Encryption Key.  
10 hexadecimal digits or 5 ASCII chars can be entered for 64-bit WEP Encryption Key.

[Table 15](#) lists the parameters for the **Shared Key** authentication mode.

[Table 15](#) Parameters for Shared Key Authentication Mode

Parameter	Description
Choose SSID	Current SSID
Authentication Type	Current SSID authentication mode
WEP Encryption	To enable or disable WEP encryption
WEP Encryption Level	WEP encryption length <ul style="list-style-type: none"> <li>The 128-bit encryption can be a 13-bit ASCII codes or a 26-bit hexadecimal number.</li> <li>The 64-bit encryption can be a 5-bit ASCII code or a 10-bit hexadecimal number.</li> </ul> Generally, the 64-bit encryption can meet the user requirements. To enhance security, use the 128-bit encryption.
WEP Key Index	Current encryption value
WEP Key1	WEP encryption value Range: 5-bit ASCII code or 10-bit hexadecimal number

Parameter	Description
WEP Key2	WEP encryption value Range: 5-bit ASCII code or 10-bit hexadecimal number
WEP Key3	WEP encryption value Range: 5-bit ASCII code or 10-bit hexadecimal number
WEP Key4	WEP encryption value Range: 5-bit ASCII code or 10-bit hexadecimal number

- c. In **Authentication Type**, select **WPA-PSK**. The **WPA-PSK** configuration information is displayed, as shown in [Figure 26](#).

Figure 26 WPA-PSK Configuration

[Table 16](#) lists the parameters for the **WPA-PSK** authentication mode.

[Table 16](#) Parameters for WPA-PSK Authentication Mode

Parameter	Description
Choose SSID	Current SSID
Authentication Type	Current SSID authentication mode
WPA Passphrase	WPA pre-shared key Range: 8 – 63 characters
WPA Group Key Update Interval	Update interval of the WPA group key
WPA Encryption Algorithm	WPA encryption algorithm



**Note**

The configuration method for the **WPA2-PSK** authentication mode is the same as that for the **WPA-PSK** authentication mode.

- Click **Submit** to finish the configuration. Click **Cancel** to cancel the configuration.
- End of Steps –

### Result

The security properties are configured.

## 4.2.4 Viewing Associated Devices

### ShortDescription

Perform this procedure to view the associated devices.

### Pre-requisites

The user has logged in to the Web interface of the device.


### Context

To view the associated devices, perform the following steps:

### Steps

- On the **Network** tab, select **WLAN**, and then select **Associated Device**, as shown in [Figure 27](#).

Figure 27 Associated Device



The screenshot shows the ZTE F660 web interface. The top navigation bar includes 'Status', 'Network', 'Security', 'Application', 'Administration', and 'Logout'. The 'Network' tab is selected, and the 'WLAN' sub-tab is active. Under 'WLAN', the 'Associated Device' option is selected. A dropdown menu for 'Choose SSID' is set to 'SSID1'. Below this, a table lists associated devices:

IP Address	MAC Address
192.168.1.4	00:17:3f:52:c1:b6

A 'Refresh' button is located at the bottom right of the table area. The footer contains the copyright notice: 'Copyright © 2008 ZTE Corporation. All rights reserved.'

- Select **SSID**, and then click **Refresh** to view the MAC addresses of the associated devices.

– End of Steps –

### Result

The associated devices are listed.

## 4.3 Address Management Configuration

This topic includes the following:

- Configuring DHCP Server
- Configuring DHCP Binding
- Configuring Specific Address Range

### 4.3.1 Configuring DHCP Server

#### ShortDescription

Perform this procedure to configure the DHCP server.

#### Pre-requisites

The user has logged in to the Web interface of the device.

#### Context

To configure the DHCP server, perform the following steps:

#### Steps

1. On the **Network** tab, select **Address Management**. By default, **DHCP Server** is selected, as shown in [Figure 28](#).

Figure 28 DHCP Server

The screenshot shows the ZTE ZXN10 F660 web interface. The top navigation bar includes 'Status', 'Network', 'Security', 'Application', 'Administration', and 'Logout'. The left sidebar menu is expanded to 'Address Management', with 'DHCP Server' selected. The main configuration area includes the following fields:

- LAN IP Address: 192.168.1.1
- Subnet Mask: 255.255.255.0
- Enable DHCP Server:
- DHCP Start IP Address: 192.168.1.2
- DHCP End IP Address: 192.168.1.254
- DNS Server1 IP Address: 192.168.1.1
- DNS Server2 IP Address: (empty)
- DNS Server3 IP Address: (empty)
- Default Gateway: 192.168.1.1
- Lease Time: 86400 sec

Below the fields is a table titled 'Allocated Address' with columns: MAC Address, IP Address, Remaining Lease Time, and Host Name. The table content is: 'There is no data item.'

At the bottom of the configuration area are 'Submit' and 'Cancel' buttons.

2. On the **DHCP Server** tab, configure the parameters, as listed in [Table 17](#).

Table 17 Parameters for DHCP Server Configuration

Parameter	Description
LAN IP Address	IP address of the LAN group (interface subnet)
Subnet Mask	Subnet mask of the LAN group
Enable DHCP Server	To enable or disable the DHCP server
DHCP Start IP Address	Starting IP address allocated by the DHCP server
DHCP End IP Address	Ending IP address allocated by the DHCP server
DNS Server1 IP Address	IP address of the DNS server
DNS Server2 IP Address	IP address of the DNS server
DNS Server3 IP Address	IP address of the DNS server
Default Gateway	IP address of the default gateway
Lease Time	Lease time of the IP address by the DHCP server

3. Click **Submit** to finish the configuration. Click **Cancel** to cancel the configuration.

– End of Steps –

### Result

The DHCP server is configured.

## 4.3.2 Configuring DHCP Binding

### ShortDescription

Perform this procedure to configure the DHCP binding.

### Pre-requisites

The user has logged in to the Web interface of the device.

### Context

To configure the DHCP binding, perform the following steps:

### Steps

1. On the **Network** tab, select **Address Management**, and then select **DHCP Binding**, as shown in [Figure 29](#).

Figure 29 DHCP Binding

2. Configure binding between the MAC address and IP address. Create a DHCP binding table to map the client MAC address to the IP address.

The DHCP server allocates IP addresses according to the binding relations, and the binding relations do not expire.

For example, if the MAC address is set to 00-0a-e2-c6-48-ba and the IP address is set to 192.168.1.113, it indicates that the DHCP server allocates the IP address 192.168.1.113 to the host which the MAC address corresponds to.



#### Note

The IP address belongs to the address pool that is provided by the DHCP server in the LAN group.

3. Click **Add** to finish the configuration. Click **Modify** to modify the configuration. Click **Delete** to delete the configuration.

– End of Steps –

#### Result

DHCP binding is configured.

### 4.3.3 Configuring Specific Address Range

#### ShortDescription

Perform this procedure to configure the specific address range.

#### Pre-requisites

The user has logged in to the Web interface of the device.


#### Context

To configure the special address range, perform the following steps:

### Steps


1. On the **Network** tab, select **Address Management**, and then select **Specific Address Range**, as shown in Figure 30.

Figure 30 Specific Address Range



2. Click **Modify** to modify the parameters, as shown in Figure 31.

Figure 31 Specific Address Range Configuration



3. In **Start IP Address** and **End IP Address**, enter the IP addresses, and then click **Modify**.

– End of Steps –

### Result

The specific address range is configured.

## 4.4 Route Management Configuration

This topic includes the following:

- Configuring Default Gateway
- Configuring Static Routing

## 4.4.1 Configuring Default Gateway

### ShortDescription

Perform this procedure to configure the default gateway.

### Pre-requisites

The user has logged in to the Web interface of the device.


### Context

To configure the default gateway, perform the following steps:

### Steps

1. On the **Network** tab, select **Routing Management**. By default, **Default Gateway** is selected, as shown in [Figure 32](#).

Figure 32 Default Gateway



2. From **WAN Connection**, select the connection interface at the WAN side.



#### Note

This interface is available when configured on **WAN Connection**.

3. Click **Submit** to finish the configuration. Click **Cancel** to cancel the configuration.

– End of Steps –

### Result

The default gateway is configured.

## 4.4.2 Configuring Static Routing

### ShortDescription

Perform this procedure to configure the static routing.

### Pre-requisites

The user has logged in to the Web interface of the device.


### Context

To configure the static routing, perform the following steps:

### Steps

1. On the **Network** tab, select **Routing Management**, and then select **Static Routing**, as shown in [Figure 33](#).

Figure 33 Static Routing



Copyright © 2008 ZTE Corporation. All rights reserved.

[Table 18](#) lists the parameters for static routing configuration.

[Table 18](#) Parameters for Static Routing Configuration

Parameter	Description
WAN Connection	Network-side interface type
Network Address	Network address
Subnet Mask	Subnet mask
Default Gateway	Gateway

2. From the **WAN Connection** drop-down list, select the network-side interface.
3. Configure **Network Address**, **Subnet Mask**, and **Default Gateway**, as shown in [Figure 34](#).

Figure 34 Static Routing Configuration

Copyright © 2008 ZTE Corporation. All rights reserved.

- Click **Add** to finish the configuration, as shown in Figure 35. Click **Modify** to modify the configuration. Click **Delete** to delete the configuration.

Figure 35 Static Routing Configuration Completed

Copyright © 2008 ZTE Corporation. All rights reserved.

– End of Steps –

## Result

The static routing is configured.



# Chapter 5

## Security Configuration

### Table of Contents

Configuring Firewall.....	5-1
Configuring IP Filter.....	5-2
Configuring URL Filter.....	5-5
Configuring DMZ Host.....	5-7
Configuring Port Forwarding.....	5-8

## 5.1 Configuring Firewall

### ShortDescription

Perform this procedure to configure the firewall.

### Pre-requisites

The user has logged in to the Web interface of the device.

### Context

To configure the firewall, perform the following steps:

### Steps

1. On the Web interface, click the **Security** tab. By default, **Firewall** is selected, as shown in [Figure 36](#).

Figure 36 Firewall Configuration



- Set the firewall parameters, as listed in [Table 19](#).

**Table 19 Firewall Parameters**

Parameter	Description
Enable Anti-Hacking Protection	To enable or disable anti-hacking protection
Firewall Level	Firewall level <ul style="list-style-type: none"> <li>● <b>High:</b> Allow legal WAN-side access but prohibit WAN-side ping.</li> <li>● <b>Low:</b> Allow legal WAN-side access and WAN-side ping.</li> </ul>

- Click **Submit** to finish the configuration. Click **Cancel** to cancel the configuration.
- End of Steps –

### Result

The firewall is configured.

## 5.2 Configuring IP Filter

### ShortDescription

Perform this procedure to configure IP filter.

### Pre-requisites

The user has logged in to the Web interface of the device.

### Context

To configure IP filter, perform the following steps:

### Steps

- On the **Security** tab, select **IP Filter**, as shown in [Figure 37](#).

Figure 37 IP Filter

ZTE中兴 ZXN10 | F660

Status Network Security Application Administration Logout

Firewall  
 IP Filter  
 URL Filter  
 DMZ Host  
 Port Forwarding

Enable   
 Protocol TCP  
 Name  
 Start Source IP Address  
 End Source IP Address  
 Start Destination IP Address  
 End Destination IP Address  
 Start Source Port  
 End Source Port  
 Start Destination Port  
 End Destination Port  
 Ingress  
 Egress  
 Mode Discard  
 Add

Enable	Name	Start Source IP Address	End Source IP Address	Start Destination IP Address	End Destination IP Address	Start Source Port	End Source Port	Start Destination Port	End Destination Port	Ingress	Egress	Mode	Modify	Delete
There is no data item, please add one first.														

Copyright © 2008 ZTE Corporation. All rights reserved.

Table 20 lists the parameters for IP filter configuration.

Table 20 Parameters for IP Filter Configuration

Parameter	Description
Enable	To enable the IP filter function
Protocol	Protocol
Name	Name
Start Source IP Address	Starting source IP address
End Source IP Address	Ending source IP address
Start Destination IP Address	Starting destination IP address
End Destination IP Address	Ending destination IP address
Start Source Port	Starting source port number
End Source Port	Ending source port number
Start Destination Port	Starting destination port number
End Destination Port	Ending destination port number
Ingress	Ingress interface
Egress	Egress interface
Mode Discard Permit	Mode, including discard and permit

- On the **IP Filter** tab, set the filter parameters, as shown in [Figure 38](#).

Figure 38 IP Filter Configuration

- Click **Add** to finish the configuration, as shown in [Figure 39](#). Click **Modify** to modify the configuration. Click **Delete** to delete the configuration.

Figure 39 IP Filter Configuration Completed

Enable	Name	Start Source IP Address	Start Source Port	Start Destination IP Address	Start Destination Port	Ingress	Egress	Modify	Delete
1	7	192.168.1.25	21	192.169.1.24	21	omc1			
TCP	Permit	192.168.1.32	21	192.169.1.35	21	LAN			

Copyright © 2008 ZTE Corporation. All rights reserved.

– End of Steps –

### Result

IP filter is configured.

## 5.3 Configuring URL Filter

### ShortDescription

Perform this procedure to configure the URL filter.

### Pre-requisites

The user has logged in to the Web interface of the device.

### Context

To configure the URL filter, perform the following steps:

### Steps

1. On the **Security** tab, select **URL Filter**, as shown in [Figure 40](#).

Figure 40 URL Filter



Table 21 lists the parameters for URL filter configuration.

Table 21 Parameters for URL Filter Configuration

Parameter	Description
Enable	To enable the URL filter function
Mode	Mode, including discard and permit
URL Address	URL address

- On the **URL Filter** tab, set the filter parameters, as shown in Figure 41.

Figure 41 URL Filter Configuration



- Click **Add** to finish the configuration, as shown in Figure 42. Click **Delete** to delete the configuration.

Figure 42 URL Filter Configuration Completed



– End of Steps –

### Result

URL filter is configured.

## 5.4 Configuring DMZ Host

### ShortDescription

Perform this procedure to configure the DMZ host.

### Pre-requisites

The user has logged in to the Web interface of the device.


### Context

To configure the DMZ host, perform the following steps:

### Steps

1. On the **Security** tab, select **DMZ Host**, as shown in [Figure 43](#).

Figure 43 DMZ Host



- Configure the DMZ host parameters, as shown in [Figure 44](#).

Figure 44 DMZ Host Configuration



[Table 22](#) lists the parameters for DMZ host configuration.

Table 22 Parameters for DMZ Host Configuration

Parameter	Description
Enable	To enable the DMZ host
WAN Connection	WAN-side connection interface
DMZ Host IP Address	IP address of the DMZ host

**Note**

After the DMZ full port mapping function is enabled, all the ports are enabled by default. The LAN-side host provides services through DNAT.

- Click **Submit** to finish the configuration. Click **Cancel** to cancel the configuration.
- End of Steps –

**Result**

The DMZ host is configured.

## 5.5 Configuring Port Forwarding

**ShortDescription**

Perform this procedure to configure port forwarding.

**Pre-requisites**

The user has logged in to the Web interface of the device.

## Context

To configure port forwarding, perform the following steps:

## Steps

1. On the **Security** tab, select **Port Forwarding**, as shown in [Figure 45](#).

Figure 45 Port Forwarding

Copyright © 2008 ZTE Corporation. All rights reserved.

2. Configure the port forwarding parameters, as shown in [Figure 46](#).

Figure 46 Port Forwarding Configuration

Copyright © 2008 ZTE Corporation. All rights reserved.

[Table 23](#) lists the parameters for port forwarding configuration.

Table 23 Parameters for Port Forwarding Configuration

Parameter	Description
Enable	To enable the port forwarding function
Name	Host name
Protocol	Protocol name, including TCP, UDP, as well as TCP and UDP protocols
WAN Host IP Address	Starting IP address of the WAN-side host
WAN Connection	WAN connection
WAN Start Port	Starting port number of the WAN-side host
WAN End Port	Ending port number of the WAN-side host
LAN Host IP Address	IP address of the LAN-side host
LAN Host Port	Port number of the LAN-side host

**Note**

If a redirection policy of port access with the source address of the WAN-side IP address and the destination address of the LAN-side IP address is configured, it is used in the scenario where the WAN-side client accesses the LAN-side server.

3. Click **Add** to finish the configuration, as shown in [Figure 47](#). Click **Modify** to modify the configuration. Click **Delete** to delete the configuration.

Figure 47 Port Forwarding Configuration Completed

Enable	Name	WAN Host IP Address	WAN Start Port	LAN Host Port	Modify	Delete
0	test	192.168.1.25	12	22		
	TCP	omci1	22	192.168.1.2		

Copyright © 2008 ZTE Corporation. All rights reserved.

– End of Steps –

### Result

Port forwarding is configured.



# Chapter 6

## Service Configuration

---

### Table of Contents

SIP VoIP Service Configuration .....	6-1
Configuring DDNS .....	6-9
Configuring UPnP .....	6-11
DNS Configuration .....	6-13
QoS Configuration .....	6-15
Configuring SNTP Client .....	6-25
IGMP Configuration .....	6-27
Configuring FTP Application .....	6-34

## 6.1 SIP VoIP Service Configuration

This topic includes the following:

- Configuring VoIP WAN Connection
- Configuring SIP
- Configuring SIP Accounts
- Configuring VoIP Advanced Parameters
- Configuring VoIP Media Parameters
- Configuring Fax

### 6.1.1 Configuring VoIP WAN Connection

#### ShortDescription

Perform this procedure to configure the VoIP WAN connection.

#### Pre-requisites

The user has logged in to the Web interface of the device.


#### Context

To configure the VoIP WAN connection, perform the following steps:

## Steps

1. On the Web interface, click the **Application** tab. Select **VoIP**. By default, **WAN Connection** is selected, as shown in [Figure 48](#).

Figure 48 WAN Connection



2. Select a connection interface from **WAN Connection**.
3. Click **Submit** to finish the configuration. Click **Cancel** to cancel the configuration.

– End of Steps –

## Result

The VoIP WAN connection is configured.

## 6.1.2 Configuring SIP

### ShortDescription

Perform this procedure to configure SIP.

### Pre-requisites

The user has logged in to the Web interface of the device.

### Context

To configure SIP, perform the following steps:

## Steps

1. On the **Application** tab, select **VoIP**, and then select **SIP Protocol**, as shown in [Figure 49](#).

Figure 49 SIP Protocol

2. Configure the SIP protocol parameters, as listed in [Table 24](#).

Table 24 Parameters for SIP Protocol Configuration

Parameter	Description
Local Port	Local port number used by the VoIP protocol
Primary Proxy Server	IP address of the primary proxy server
Primary Outbound Proxy Server	IP address of the primary outbound proxy server
Primary Proxy Port	Port number of the primary proxy server
Secondary Proxy Server	IP address of the secondary proxy server
Secondary Outbound Proxy Server	IP address of the secondary outbound proxy server
Secondary Proxy Port	Port number of the secondary proxy server
Register Expires	Registration expiration time Unit: second

3. Click **Submit** to finish the configuration. Click **Cancel** to cancel the configuration.

– End of Steps –

## Result

SIP is configured.

## 6.1.3 Configuring SIP Accounts

### ShortDescription

Perform this procedure to configure SIP accounts.

### Pre-requisites

The user has logged in to the Web interface of the device.


### Context

To configure SIP accounts, perform the following steps:

### Steps

1. On the **Application** tab, select **VoIP**, and then select **SIP Accounts**, as shown in [Figure 50](#).

Figure 50 SIP Accounts



The screenshot shows the ZTE web interface for the ZXA10 F660 device. The 'Application' tab is selected, and the 'SIP Accounts' option is highlighted in the left-hand menu. The main content area contains three input fields: 'Username', 'Password', and 'URI'. Below these fields is a table listing existing SIP accounts.

Username	URI	Modify
6662000	sip:6662000@10.40.110	
6662001	sip:6662001@10.40.110	

2. Click **Modify** to modify the account parameters, as shown in [Figure 51](#).

Figure 51 SIP Account Configuration

Username	URI	Modify
6662000	sip:6662000@10.40.110	
6662001	sip:6662001@10.40.110	

Table 25 lists the parameters for SIP account configuration.

Table 25 Parameters for SIP Account Configuration

Parameter	Description
Username	Name of the SIP authentication user
Password	Password of the SIP authentication user
URI	User registration identification, that is, the user SIP call number

- Click **Modify**.

– End of Steps –

### Result

The SIP accounts are configured.

## 6.1.4 Configuring VoIP Advanced Parameters

### ShortDescription

Perform this procedure to configure the VoIP advanced parameters.

### Pre-requisites

The user has logged in to the Web interface of the device.


## Context

To configure the VoIP advanced parameters, perform the following steps:

## Steps

1. On the **Application** tab, select **VoIP**, and then select **Advanced**, as shown in [Figure 52](#).

Figure 52 Advanced Parameters



2. Configure the advanced parameters, as shown in [Table 26](#).

Table 26 Advanced Parameters

Parameter	Description
Echo Cancellation	To enable or disable echo cancellation
VAD&CNG	To enable or disable VAD and CNG
DTMF	DTMF mode, including RFC2833, RFC2198, and DTMF in Voice
Jitter Buffer	Jitter buffer, including fixed and adaptive
Min Value	Minimum jitter buffer value Unit: ms
Max Value	Maximum jitter buffer value Unit: ms

3. Click **Submit** to finish the configuration. Click **Cancel** to cancel the configuration.

– End of Steps –

## Result

The VoIP advanced parameters are configured.

## 6.1.5 Configuring VoIP Media Parameters

### ShortDescription

Perform this procedure to configure the VoIP media parameters.

### Pre-requisites

The user has logged in to the Web interface of the device.

### Context

To configure VoIP media parameters, perform the following steps:

### Steps

1. On the **Application** tab, select **VoIP**, and then select **Media**, as shown in [Figure 53](#).

Figure 53 Media Parameters

The screenshot shows the ZTE ZXN10 F660 web interface. The top navigation bar includes tabs for Status, Network, Security, Application, Administration, and Logout. The 'Application' tab is selected, and the 'VoIP' menu is expanded to show 'Media' as the active sub-tab. The configuration area for 'Media' includes:

- Codec Selection:** Four checkboxes for G.711U, G.711A, G.729, and G.723.
- Codec Priority 1 - 16 (Smaller value represents higher priority):** Four input fields for G.711U, G.711A, G.729, and G.723.

At the bottom right of the configuration area, there are 'Submit' and 'Cancel' buttons.

2. Configure the media parameters, as shown in [Figure 54](#).

Figure 54 Media Parameter Configuration



Table 27 lists the media parameters.

Table 27 Media Parameters

Parameter	Description
Codec Selection	Code type
Codec Priority	Code priority The smaller the value is, the higher the priority is.

3. Click **Submit** to finish the configuration. Click **Cancel** to cancel the configuration.

– End of Steps –

**Result**

The VoIP media parameters are configured.

## 6.1.6 Configuring Fax

**ShortDescription**

Perform this procedure to configure fax.

**Pre-requisites**

The user has logged in to the Web interface of the device.


**Context**

To configure fax, perform the following steps:

## Steps

1. On the **Application** tab, select **VoIP**, and then select **Fax**, as shown in [Figure 55](#).

Figure 55 Fax Configuration



2. Select **Enable T38**.



### Note

To disable T38 fax mode, clear the check box.

3. Click **Submit** to finish the configuration. Click **Cancel** to cancel the configuration.

– End of Steps –

## Result

Fax is configured.

## 6.2 Configuring DDNS

### ShortDescription

Perform this procedure to configure DDNS.

### Pre-requisites

The user has logged in to the Web interface of the device.

## Context


After DDNS is applied, the host that has the dynamic IP address can also provide the domain name service. For example, when the host obtains an IP address through xDSL dial-up or DHCP server dynamic allocation, and the host provides the domain name service, by using DDNS, the effect on the domain name access when the IP address changes is eliminated.

To configure DDNS, perform the following steps:

## Steps

1. On the **Application** tab, select **DDNS**, as shown in [Figure 56](#).

Figure 56 DDNS



Copyright © 2008 ZTE Corporation. All rights reserved.

2. Configure the DDNS parameters, as shown in [Figure 57](#).

Figure 57 DDNS Configuration



Copyright © 2008 ZTE Corporation. All rights reserved.

[Table 28](#) lists the parameters for DDNS configuration.

Table 28 Parameters for DDNS Configuration

Parameter	Description
Enable	To enable the DDNS function
Server	Server address If the GNUMIP HTTP protocol is used, the sever address is a URL address. By default, it is <a href="http://ns.eagleeyes.com.cn/cgi-bin/gdipupdt.cgi">http://ns.eagleeyes.com.cn/cgi-bin/gdipupdt.cgi</a> .
Username	DDNS server user name
Password	DDNS server password
Domain	Domain name corresponding to the user, valid only when the GNUMIP protocol is used
WAN Connection	WAN-side connection interface

- Click **Submit** to finish the configuration. Click **Cancel** to cancel the configuration.

– End of Steps –

### Result

DDNS is configured.

## 6.3 Configuring UPnP

### ShortDescription

Perform this procedure to configure UPnP.

### Pre-requisites

The user has logged in to the Web interface of the device.

### Context

The UPnP function supports zero configuration and device auto-discovery. After this function is configured, the device can be dynamically added to a network to obtain the IP address, announce the function, and know the functions of other devices.

To configure UPnP, perform the following steps:

### Steps

- On the **Application** tab, select **UPnP**, as shown in [Figure 58](#).

Figure 58 UPnP



2. Configure the UPnP parameters, as shown in Figure 59.

Figure 59 UPnP Configuration




Table 29 lists the UPnP parameters.

Table 29 UPnP Parameters

Parameter	Description
Enable	To enable UPnP
WAN Connection omci1	WAN-side connection interface

3. Click **Submit** to finish the configuration. Click **Cancel** to cancel the configuration.

– End of Steps –

**Result**

UPnP is configured.

## 6.4 DNS Configuration

This topic includes the following:

- Configuring Domain Name
- Configuring Host Name

### 6.4.1 Configuring Domain Name

#### ShortDescription

Perform this procedure to configure the domain name.

#### Pre-requisites

The user has logged in to the Web interface of the device.

#### Context

To configure the domain name, perform the following steps:

#### Steps

1. On the **Application** tab, select **DNS Service**. By default, **Domain Name** is selected, as shown in [Figure 60](#).

Figure 60 Domain Name



The screenshot shows the ZTE ZX10 F660 web interface. The top navigation bar includes tabs for Status, Network, Security, Application, Administration, and Logout. The 'Application' tab is active, and the 'DNS Service' menu item is expanded, showing 'Domain Name' as the selected option. Below the menu, there is a text input field labeled 'Domain Name'. At the bottom of the page, there are 'Submit' and 'Cancel' buttons. The footer contains the text: 'Copyright © 2008 ZTE Corporation. All rights reserved.'

2. Set **Domain Name**.
3. Click **Submit** to finish the configuration. Click **Cancel** to cancel the configuration.

– End of Steps –

#### Result

The domain name is configured.

## 6.4.2 Configuring Host Name

### ShortDescription

Perform this procedure to configure the host name.

### Pre-requisites

The user has logged in to the Web interface of the device.


### Context

To configure the host name, perform the following steps:

### Steps

1. On the **Application** tab, select **DNS Service**, and then select **Hosts**, as shown in [Figure 61](#).

Figure 61 Host Name



The screenshot shows the ZTE web interface for the ZXA10 F660 device. The 'Application' tab is selected, and the 'Hosts' sub-tab under 'DNS Service' is active. The interface includes a navigation menu on the left with options like VoIP, DDNS, UPnP, DNS Service, Hosts, QoS, SNTP, IGMP, and FTP Server. The main content area has input fields for 'Host Name' and 'IP Address', and an 'Add' button. A warning message states: 'The items with disabled buttons are allocated from a DHCP server, which couldn't be operated.' Below this is a table with columns 'Host Name', 'IP Address', and 'Modify Delete', containing the message 'There is no data item, please add one first.' The footer contains the copyright notice: 'Copyright © 2008 ZTE Corporation. All rights reserved.'

2. Set **Host Name** and **IP Address**, as shown in [Figure 62](#).

Figure 62 Host Name Configuration

ZTE中兴 ZXN10 | F660

Status Network Security **Application** Administration Logout

+ VoIP  
 + DDNS  
 + UPnP  
 - DNS Service  
 Domain Name  
 + Hosts  
 + QoS  
 + SNMP  
 + IGMP  
 + FTP Server

Host Name:   
 IP Address:

The items with disabled buttons are allocated from a DHCP server, which couldn't be operated.

Host Name	IP Address	Modify/Delete
There is no data item, please add one first.		

Copyright © 2008 ZTE Corporation. All rights reserved.

- Click **Add** to finish the configuration, as shown in Figure 63. Click **Modify** to modify the configuration. Click **Delete** to delete the configuration.

Figure 63 Host Name Configuration Completed

ZTE中兴 ZXN10 | F660

Status Network Security **Application** Administration Logout

+ VoIP  
 + DDNS  
 + UPnP  
 - DNS Service  
 Domain Name  
 + Hosts  
 + QoS  
 + SNMP  
 + IGMP  
 + FTP Server

Host Name:   
 IP Address:

The items with disabled buttons are allocated from a DHCP server, which couldn't be operated.

Host Name	IP Address	Modify/Delete
F660	192.168.1.1	

Copyright © 2008 ZTE Corporation. All rights reserved.

– End of Steps –

## Result

The host name is configured.

## 6.5 QoS Configuration

This topic includes the following:

- Configuring Basic QoS Parameters
- Configuring QoS Rule
- Configuring QoS Rule Type
- Configuring QoS Local Application
- Configuring QoS Queue Management

- Configuring QoS Ingress Rate Limit

## 6.5.1 Configuring Basic QoS Parameters

### ShortDescription

Perform this procedure to configure the basic QoS parameters.

### Pre-requisites

The user has logged in to the Web interface of the device.


### Context

To configure the basic QoS parameters, perform the following steps:

### Steps

1. On the **Application** tab, select **QoS**. By default, **Basic** is selected, as shown in [Figure 64](#).

Figure 64 Basic QoS Parameters



The screenshot shows the ZTE web interface for configuring QoS parameters. The page title is "ZTE中兴" and the device model is "ZXA10 | F660". The navigation tabs are Status, Network, Security, Application, Administration, and Logout. The "Application" tab is selected, and the "QoS" menu item is highlighted in the left sidebar. The "Basic" sub-menu is selected. The main content area displays the following configuration options:

- Template Index: [Dropdown menu]
- Enable QoS:
- The Total Upstream Bandwidth: 0 [Input field] bps
- Queue Scheduling Algorithm: [Dropdown menu]
- Enable DSCP Re-marking:
- 802.1P Re-mark Model: [Dropdown menu]

At the bottom of the configuration area, there are "Submit" and "Cancel" buttons. A copyright notice at the bottom reads: "Copyright © 2008 ZTE Corporation. All rights reserved."



### Note

The template index is enabled immediately after changed.

2. Configure the basic QoS parameters, as shown in [Figure 65](#).

Figure 65 Basic QoS Parameter Configuration

Table 30 lists the basic QoS parameters.

Table 30 Basic QoS Parameters

Parameter	Description
Template Index	Template index
Enable QoS	To enable or disable the QoS function
The Total Upstream Bandwidth	Upstream bandwidth through the WAN port Range: 8000 – 104857600 bps
Queue Scheduling Algorithm	Queue scheduling algorithm Range: SP and DWRR
DWRR bandwidth locked	To lock DWRR bandwidth (when the queue scheduling algorithm is DWRR)
Enable DSCP Re-marking	To enable or disable DSCP remarking
802.1P Re-mark Model	To enable or disable the 802.1p remarking mode Range: disable, transparent transmission, and enable

- Click **Submit** to finish the configuration. Click **Cancel** to cancel the configuration.

– End of Steps –

### Result

The basic QoS parameters are configured.

## 6.5.2 Configuring QoS Rule

### ShortDescription

Perform this procedure to configure the QoS rule.

### Pre-requisites

The user has logged in to the Web interface of the device.

### Context

To configure the QoS rule, perform the following steps:

### Steps

1. On the **Application** tab, select **QoS**, and then select **Rule**, as shown in [Figure 66](#).

Figure 66 QoS Rule



ZTE中兴 ZX10 | F660

Status Network Security Application Administration Logout

VoIP  
DDNS  
UPnP  
DNS Service  
QoS  
Rule  
Local Application  
Queue Management  
Ingress Rate Limit  
SNTP  
IGMP  
FTP Server

802.1p Re-marking (0-7)  
DSCP Re-marking (0-63)  
CAR(Committed Access Rate) (1-10)  
Queue 1

Add

Priority	Modify	Delete
There is no data item, please add one first.		

Copyright © 2008 ZTE Corporation. All rights reserved.

2. Configure the QoS rule parameters, as shown in [Figure 67](#).

Figure 67 QoS Rule Configuration

Table 31 lists the parameters for QoS rule configuration.

Table 31 Parameters for QoS Rule Configuration

Parameter	Description
802.1p Re-marking	802.1P remarking
DSCP Re-marking	DSCP remarking
CAR(Committed Access Rate)	Ingress rate limit rule
Queue	Congestion management queue

- Click **Submit** to finish the configuration. Click **Cancel** to cancel the configuration.

– End of Steps –

### Result

The QoS rule is configured.

## 6.5.3 Configuring QoS Rule Type

### ShortDescription

Perform this procedure to configure the QoS rule type.

### Pre-requisites

The user has logged in to the Web interface of the device.

### Context

To configure the QoS rule type, perform the following steps:

## Steps

1. On the **Application** tab, select **QoS**, and then select **Rule Type**, as shown in [Figure 68](#).

Figure 68 Rule Type



2. Configure the QoS rule type parameters, as shown in [Figure 69](#).

Figure 69 Rule Type Configuration



[Table 32](#) lists the parameters for QoS rule type Configuration

Table 32 Parameters for QoS Rule Type Configuration

Parameter	Description
Classification Rules	Classification rules

Parameter	Description
Protocol	Protocol Range: TCP, UDP, ICMP, and RTP
Type	Type
Minimum	Minimum value
Maximum	Maximum value

- Click **Add** to finish the configuration, as shown in [Figure 70](#).

Figure 70 Rule Type Configuration Completed

The screenshot shows the ZTE ZX10 F660 web interface. The 'Application' tab is selected, and the 'Rule Type' configuration is displayed. The 'Classification Rules' dropdown is set to '1'. The 'Protocol' section has checkboxes for TCP, UDP, ICMP, and RTP. The 'Type' dropdown is set to 'Source MAC'. There are input fields for 'Minimum' and 'Maximum' values, and an 'Add' button. Below the configuration form, a table lists the configured rule types:

Type	Modify	Delete
SMAC		

Copyright © 2008 ZTE Corporation. All rights reserved.

- Click **Modify** to modify the configuration. Click **Delete** to delete the configuration.
- End of Steps –

### Result

The QoS rule type is configured.

## 6.5.4 Configuring QoS Local Application

### ShortDescription

Perform this procedure to configure the QoS local application.

### Pre-requisites

The user has logged in to the Web interface of the device.

### Context

To configure the QoS local application, perform the following steps:

## Steps

1. On the **Application** tab, select **QoS**, and then select **Local Application**, as shown in Figure 71.

Figure 71 Local Application



2. In the **Queue** drop-down list, select a queue number.



### Note

At present, only the Tr-069 service mode is supported.

3. Click **Submit** to finish the configuration. Click **Cancel** to cancel the configuration.

– End of Steps –

## Result

The QoS local application is configured.

## 6.5.5 Configuring QoS Queue Management

### ShortDescription

Perform this procedure to configure QoS queue management.

### Pre-requisites

The user has logged in to the Web interface of the device.

### Context

To configure QoS queue management, perform the following steps:

## Steps

1. On the **Application** tab, select **QoS**, and then select **Queue Management**, as shown in Figure 72.

Figure 72 Queue Management

Enable	Queue Index	Modify
1	1	
1	2	
0	3	
1	4	

2. Click the **Modify** icons in the table to modify the queue management functions.
3. Select or clear **Enable** to enable or disable the queue management function.
4. Click **Modify** to finish the configuration.



### Note

1 indicates enabled and 0 indicates disabled.

When the congestion management algorithm is DWRR, the queue weight needs to be configured.

Weight refers to the ratio of the data flow passing through the queues to the total data flow.

– End of Steps –

## Result

QoS queue management is configured.

## 6.5.6 Configuring QoS Ingress Rate Limit

### ShortDescription

Perform this procedure to configure the QoS ingress rate limit.

### Pre-requisites

The user has logged in to the Web interface of the device.

### Context

To configure the QoS ingress rate limit, perform the following steps:

### Steps

1. On the **Application** tab, select **QoS**, and then select **Ingress Rate Limit**, as shown in [Figure 73](#).

Figure 73 Ingress Rate Limit



2. Configure the parameters for QoS ingress rate limit, as shown in [Figure 74](#).

Figure 74 Ingress Rate Limit Configuration



Table 33 lists the parameters for ingress rate limit configuration.

Table 33 Parameters for Ingress Rate Limit Configuration

Parameter	Description
Visiting Interface	User interface for the rate limit rule
Enable	To enable the ingress rate limit function
Rate	Limit rate 8000 bps – 104857600 bps

- Click **Add** to finish the configuration. Click **Modify** to modify the configuration. Click **Delete** to delete the configuration.

– End of Steps –

### Result

The QoS ingress rate limit is configured.

## 6.6 Configuring SNTP Client

### ShortDescription

Perform this procedure to configure the SNTP client.

### Pre-requisites

The user has logged in to the Web interface of the device.


### Context

To configure the SNTP client, perform the following steps:

### Steps

- On the **Application** tab, select **SNTP**, as shown in [Figure 75](#).

Figure 75 SNTP



2. Configure the SNTP parameters, as shown in Figure 75.

Figure 76 SNTP Configuration




Table 34 lists the SNTP parameters.

Table 34 SNTP Parameters

Parameter	Description
Time Zone	Time zone where the subscriber is located
Primary NTP Server Address	IP address of the primary NTP server
Secondary NTP Server Address	IP address of the secondary NTP server
Poll Interval	Interval for server synchronization Unit: second

3. Click **Submit** to finish the configuration. Click **Cancel** to cancel the configuration.

– End of Steps –

## Result

The SNTP client is configured.

# 6.7 IGMP Configuration

This topic includes the following:

- Configuring Basic IGMP Parameters
- Configuring Multicast VLAN
- Configuring Multicast MAC Limit
- Configuring MVLAN Tag Strip

## 6.7.1 Configuring Basic IGMP Parameters

### ShortDescription

Perform this procedure to configure the basic IGMP parameters.

### Pre-requisites

The user has logged in to the Web interface of the device.

### Context

To configure the basic IGMP parameters, perform the following steps:

### Steps

1. On the **Application** tab, select **IGMP**. By default, **Basic** is selected, as shown in [Figure 77](#).

Figure 77 Basic IGMP Configuration

The screenshot shows the ZTE ZX10 F660 web interface. The top navigation bar includes 'Status', 'Network', 'Security', 'Application', 'Administration', and 'Logout'. The 'Application' tab is active. On the left sidebar, the 'IGMP' menu item is selected, and the 'Basic' sub-menu is expanded. The main configuration area shows the following settings:

- IGMP Mode: IGMP Proxy (dropdown menu)
- Multicast MAC Aging Time: (1 - 604800 s)
- Report Time: (1 - 86400 s)

At the bottom right, there are 'Submit' and 'Cancel' buttons. The footer contains the text: 'Copyright © 2008 ZTE Corporation. All rights reserved.'

2. **IGMP Mode** includes **IGMP Snooping**, **IGMP Proxy**, and **Disabled**. **Disabled** indicates to disable the IGMP mode configuration.

- Configure **IGMP Snooping**.

From the **IGMP Mode** drop-down list, select **IGMP Snooping**, as shown in [Figure 78](#).

Figure 78 IGMP Snooping Configuration



[Table 35](#) lists the parameters for IGMP snooping configuration.

Table 35 Parameters for IGMP Snooping Configuration

Parameter	Description
IGMP Mode	IGMP mode
Multicast MAC Aging Time	Aging time of the multicast address
Non-Fast-Leave	To enable the Non-Fast-Leave mode

- Configure **IGMP Proxy**.

From the **IGMP Mode** drop-down list, select **IGMP Proxy**, as shown in [Figure 79](#).

Figure 79 IGMP Proxy Configuration

Table 36 lists the parameters for IGMP proxy configuration.

Table 36 Parameters for IGMP Proxy Configuration

Parameter	Description
IGMP Mode	IGMP mode
Multicast MAC Aging Time	Aging time of the multicast address
Report Time	Periodical report time of multicast messages



#### Note

ZXA10 F660 periodically reports the IGMP member report messages to the upper-layer multicast router according to the **Report Time**.

- Click **Submit** to finish the configuration. Click **Cancel** to cancel the configuration.

– End of Steps –

#### Result

The basic IGMP parameters are configured.

## 6.7.2 Configuring Multicast VLAN

#### ShortDescription

Perform this procedure to configure the multicast VLAN.

### Pre-requisites

The user has logged in to the Web interface of the device.


### Context

To configure the multicast VLAN, perform the following steps:

### Steps


1. On the **Application** tab, select **IGMP**, and then select **Multicast VLAN**, as shown in [Figure 80](#).

Figure 80 Multicast VLAN



2. Configure the multicast VLAN parameters, as shown in [Figure 81](#).

Figure 81 Multicast VLAN Configuration



[Table 37](#) lists the parameters for the multicast VLAN configuration.

Table 37 Parameters for Multicast VLAN Configuration

Parameter	Description
IGMP Mode	IGMP mode, configured on the <b>Basic</b> tab
Enable Multicast VLAN	To enable the multicast VLAN function
Enable Translation	To enable multicast VLAN translation
Multicast VLAN	To create a multicast VLAN
New VLAN	Multicast VLAN ID
Interface Name	LAN interface to be added to the multicast VLAN

- Click **Submit** to finish the configuration. Click **Cancel** to cancel the configuration.

– End of Steps –

### Result

The multicast VLAN is configured.

## 6.7.3 Configuring Multicast MAC Limit

### ShortDescription

Perform this procedure to configure multicast MAC limit.

### Pre-requisites

The user has logged in to the Web interface of the device.

### Context


The multicast MAC limit function can be configured only when the IGMP mode is **IGMP Snooping**. **IGMP Proxy** does not support this function.

To configure multicast MAC limit, perform the following steps:

### Steps

- On the **Application** tab, select **IGMP**, and then select **Multicast MAC Limit**, as shown in [Figure 82](#).

Figure 82 Multicast MAC Limit



2. Click the **Modify** icon to configure the multicast MAC limit, as shown in Figure 83.

Figure 83 Multicast MAC Limit Configuration



Table 38 lists the parameters for the multicast MAC limit configuration.

Table 38 Parameters for Multicast MAC Limit Configuration

Parameter	Description
Multicast MAC Address Limit	Maximum multicast addresses for each LAN port Range: 0 – 256

3. Click **Modify**.  
– End of Steps –

**Result**

Multicast MAC limit is configured.

## 6.7.4 Configuring MVLAN Tag Strip

### ShortDescription

Perform this procedure to configure MVLAN tag strip.

### Pre-requisites

The user has logged in to the Web interface of the device.

### Context

The MVLAN tag strip function can be configured only when the IGMP mode is **IGMP Snooping**. **IGMP Proxy** does not support this function.

To configure MVLAN tag strip, perform the following steps:

### Steps

1. On the **Application** tab, select **IGMP**, and then select **Tag Stripe**, as shown in [Figure 84](#).

Figure 84 MVLAN Tag Strip

The screenshot shows the ZTE web interface for a ZX10 F660 device. The 'Application' tab is selected, and the 'IGMP' configuration page is open. The 'Tag Stripe' sub-tab is active. A warning message states 'IGMP Snooping mode allows configuration.' Below this, there is an 'Enable Tag Stripe' checkbox which is currently unchecked, and a 'Modify' button. A table lists the interfaces and their tag strip status:

Interface Name	Tag Stripe	Modify
LAN1	Disable	
LAN2	Disable	
LAN3	Disable	
LAN4	Disable	

Copyright © 2008 ZTE Corporation. All rights reserved.

2. Click the **Modify** icon to configure MVLAN tag strip, as shown in [Figure 85](#).

Figure 85 MVLAN Tag Strip Configuration



Table 39 lists the parameters for MVLAN tag strip configuration.

Table 39 Parameters for MVLAN Tag Strip Configuration

Parameter	Description
Enable Tag Stripe	To enable the MVLAN tag strip function

3. Click **Modify**.

– End of Steps –

### Result

MVLAN tag strip is configured.

## 6.8 Configuring FTP Application

### ShortDescription

Perform this procedure to configure FTP application.

### Pre-requisites

The user has logged in to the Web interface of the device.

### Context

To configure FTP application, perform the following steps:

### Steps

1. On the **Application** tab, select **FTP Application**, as shown in [Figure 86](#).

Figure 86 FTP Server

ZTE中兴 ZX10 | F660  
 Status Network Security **Application** Administration Logout  
 + VoIP  
 + DDNS  
 + UPnP  
 + DNS Service  
 + QoS  
 + SNTP  
 + IGMP  
 + **FTP Server**  
 Enable FTP Server   
 FTP Username   
 FTP Password   
 Submit Cancel  
 Copyright © 2008 ZTE Corporation. All rights reserved.

2. Configure the FTP server parameters, as shown in Figure 87.

Figure 87 FTP Server Configuration

ZTE中兴 ZX10 | F660  
 Status Network Security **Application** Administration Logout  
 + VoIP  
 + DDNS  
 + UPnP  
 + DNS Service  
 + QoS  
 + SNTP  
 + IGMP  
 + **FTP Server**  
 Enable FTP Server   
 FTP Username   
 FTP Password   
 Submit Cancel  
 Copyright © 2008 ZTE Corporation. All rights reserved.

Table 40 lists the FTP server parameters.

Table 40 FTP Server Parameters

Parameter	Description
Enable FTP Server	To enable the FTP server
FTP Username	FTP login user name
FTP Password	FTP login password

3. Click **Submit** to finish the configuration. Click **Cancel** to cancel the configuration.

– End of Steps –

### Result

FTP application is configured.



# Chapter 7

## Device Management

---

### Table of Contents

TR-069 Configuration .....	7-1
User Management.....	7-4
Device Management .....	7-5
Log Management .....	7-9
Ping Diagnosis .....	7-10

## 7.1 TR-069 Configuration

This topic includes the following:

- Configuring Basic TR-069 Parameters
- Importing TR-069 Certificate

### 7.1.1 Configuring Basic TR-069 Parameters

#### ShortDescription

Perform this procedure to configure the basic TR-069 parameters.

#### Pre-requisites

The user has logged in to the Web interface of the device.

#### Context

To configure the basic TR-069 parameters, perform the following steps:

#### Steps

1. On the **Administration** tab, select **TR-069**. By default, **Basic** is selected, as shown in [Figure 88](#).

Figure 88 Basic TR-069 Parameters

2. Configure the basic TR-069 parameters, as shown in Figure 89.

Figure 89 Basic TR-069 Parameter Configuration

Table 41 lists the basic TR-069 parameters.

Table 41 Basic TR-069 Parameters

Parameter	Description
WAN Connection	WAN-side connection interface
ACS URL	Network server URL
Username	User name
Password	Password
Connection Request URL	Connection request URL
Connection Request Username	Connection request user name

Parameter	Description
Connection Request Password	Connection request password
Enable Periodic Inform	To enable periodic report
Periodic Inform Interval	Periodic report interval
Enable Certificate	To enable certificate

- Click **Submit** to finish the configuration. Click **Cancel** to cancel the configuration.

– End of Steps –

### Result

The basic TR-069 parameters are configured.

## 7.1.2 Importing TR-069 Certificate

### ShortDescription

Perform this procedure to import the TR-069 certificate.

### Pre-requisites

The user has logged in to the Web interface of the device.


### Context

To import the TR-069 certificate, perform the following steps:

### Steps

- On the **Administration** tab, select **TR-069**, and then select **Certificate**, as shown in [Figure 90](#).

Figure 90 TR-069 Certificate



- Click **Browse** to select the certificate file.
- Click **Import Certificate** to import the file.

– End of Steps –

## Result

The TR-069 certificate is imported.

# 7.2 User Management

## ShortDescription

Perform this procedure to manage users.

## Pre-requisites

The user has logged in to the Web interface of the device.


## Context

To manage users, perform the following steps:

## Steps

1. On the **Administration** tab, select **User Management**, as shown in [Figure 91](#).

Figure 91 User Management



2. Configure the user management parameters.



### Note

**User Right** includes **Administrator** and **User**.

3. Click **Submit** to finish the configuration. Click **Cancel** to cancel the configuration.

– End of Steps –

## Result

User management is complete.

## 7.3 Device Management

This topic includes the following:

- System Management
- Software Upgrade
- Configuration Management

### 7.3.1 System Management

#### ShortDescription

Perform this procedure to manage the system.

#### Pre-requisites

The user has logged in to the Web interface of the device.

#### Context

To manage the system, perform the following steps:

#### Steps

1. On the **Administration** tab, select **System Management**, as shown in [Figure 92](#).

Figure 92 System Management



2. Click **Reboot** to reboot the device.
3. Click **Restore Default** to restore the system to the factory default settings.

– End of Steps –

#### Result

System management is complete.

## 7.3.2 Software Upgrade

### ShortDescription

Perform this procedure to upgrade the software.

### Pre-requisites

The user has logged in to the Web interface of the device.

### Context



#### Caution


Generally, the software is upgraded by the ZTE CORPORATION engineers. If the user wants to upgrade the software, contact the local office of ZTE CORPORATION to obtain the latest software version.

To upgrade the software, perform the following steps:

### Steps

1. On the **Administration** tab, select **System Management**, and then select **Software Upgrade**, as shown in [Figure 93](#).

Figure 93 Software Upgrade



2. Click **Browse** to select the software version.
3. Click **Upgrade** to upgrade the software, as shown in [Figure 94](#).

Figure 94 Upgrading Software



Figure 95 shows the result of software upgrade.

Figure 95 Software Upgrade Completed



**NOTE**

During the upgrade process, the device cannot be powered off; otherwise, it may be damaged.

During the upgrade process, the system prompts a message. After the upgrade is complete, the system returns to the login interface.

**– End of Steps –**

**Result**

The software is upgraded.

## 7.3.3 Configuration Management

### ShortDescription

Perform this procedure to manage the device configuration.

### Pre-requisites

The user has logged in to the Web interface of the device.


### Context

To manage the device configuration, perform the following steps:

### Steps


1. On the **Administration** tab, select **System Management**, and then select **Configuration Management**, as shown in [Figure 96](#).

Figure 96 Configuration Management



2. Click **Backup Configuration** to back up the existing configuration file.
3. Click **Browse** to select the backed up configuration file.
4. Click **Restore Configuration** to restore the backed up configuration file, as shown in [Figure 97](#).

Figure 97 Importing File Completed



– End of Steps –

### Result

The configuration management is complete.

## 7.4 Log Management

### ShortDescription

Perform this procedure to manage logs.

### Pre-requisites

The user has logged in to the Web interface of the device.

### Context

To manage logs, perform the following steps:

### Steps

1. On the **Administration** tab, select **Log Management**, as shown in [Figure 98](#).

Figure 98 Log Management

2. Configure the log management parameters, as listed in [Table 42](#).

Table 42 Log Management Parameters

Parameter	Description
Log Enable	Whether to enable the log server
Log Level	Log level, including <b>Debug</b> , <b>Informational</b> , <b>Notice</b> , <b>Warning</b> , <b>Error</b> , <b>Critical</b> , <b>Alert</b> , and <b>Emergency</b> When <b>Log Level</b> is configured, only the logs above the specified level are saved.

3. Click **Refresh** to display the latest 20 logs.
4. Click **Clear Log** to clear the current log records.
5. Click **Submit** to finish the configuration. Click **Cancel** to cancel the configuration.

– End of Steps –

### Result

Log management is complete.

## 7.5 Ping Diagnosis

### ShortDescription

Perform this procedure to diagnose ping connection.

### Pre-requisites

The user has logged in to the Web interface of the device.


### Context

To diagnose ping connection, perform the following steps:

### Steps

1. On the **Administration** tab, select **Diagnosis**, as shown in [Figure 99](#).

Figure 99 Ping Diagnosis



The screenshot shows the ZTE web interface for the ZXA10 F660 device. The top navigation bar includes tabs for Status, Network, Security, Application, Administration, and Logout. The Administration tab is selected, and the left sidebar shows a tree view with 'Diagnosis' highlighted. The main content area contains a form with a text input field labeled 'Input IP Address or host name' and a large text area below it. At the bottom of the form are 'Submit' and 'Cancel' buttons. The footer of the page reads 'Copyright © 2008 ZTE Corporation. All rights reserved.'

2. In **Input IP Address or host name** , enter the host IP address or host name.
3. Click **Submit** to diagnose the connection, as shown in [Figure 100](#). Click **Cancel** to cancel the configuration.

Figure 100 Ping Diagnosis Result

The screenshot shows the ZTE ZXN10 F660 web management interface. The top navigation bar includes 'Status', 'Network', 'Security', 'Application', 'Administration', and 'Logout'. The left sidebar contains a menu with 'TR-069', 'User Management', 'System Management', 'Log Management', and 'Diagnosis' (which is selected). The main content area displays the results of a ping test to 10.63.11.83. It shows three successful ping attempts with 64 data bytes each and round-trip times of 331.2 ms, 11.1 ms, and 11.0 ms. The statistics indicate 3 packets transmitted, 3 received, and 0% packet loss.

```
Input IP Address or host name   
PING 10.63.11.83 (10.63.11.83): 64 data bytes  
72 bytes from 10.63.11.83: icmp_seq=0 ttl=119 time=331.2 ms  
72 bytes from 10.63.11.83: icmp_seq=1 ttl=119 time=11.1 ms  
72 bytes from 10.63.11.83: icmp_seq=2 ttl=119 time=11.0 ms  
--- 10.63.11.83 ping statistics ---  
3 packets transmitted, 3 packets received, 0% packet loss  
round-trip min/avg/max = 11.1/118.0/331.2 ms
```

Submit Cancel

Copyright © 2008 ZTE Corporation. All rights reserved.

– End of Steps –

## Result

Ping diagnosis is complete.



# Appendix A

## FAQ

---

Table of Contents:

- FAQ A -1

### A .1 FAQ

#### **How Can I set TCP/IP on the Computer Connected to the Device?**

The default device IP address is 192.168.1.1. Therefore, set the computer IP address to 192.168.1.2 – 192.168.1.254 and the subnet mask to 255.255.255.0.

#### **How Can I Ensure That My Computer Is Successfully Connected to the Device?**

On the command line interface, carry out the **ping 192.168.1.1** command. If the connection fails, the interface prompts connection timeout.

#### **How Can I Set the Device Through the Web Interface?**

Make sure that the computer is connected to the device. Then open the Internet Explorer and enter `http://192.168.1.1` on the address bar to access the Web interface of the device. The default user name and password are `admin`.

#### **How Can I Restore the Device to the Factory Default Settings?**

Press the **RST** reset button for more than 10 seconds to reboot the device. Then the device is restored to the factory default settings.

#### **Why Is the PON Link Indicator Always OFF?**

If the PON link indicator is always OFF, it indicates that the PON link is not successfully set up. Make sure that the fiber is correctly connected with the PON port and the subscriber device. Make sure that the tail fiber is straight and is in good condition.

#### **Why Does the Device Fail to Make a Call?**

Check whether the telephone cable is correctly connected to the POTS1 or POTS2 port. Then access the Web interface of the device. Click the **Application** tab to check the

VoIP configuration. If the VoIP configuration is correct and the telephone cable is correctly connected, but the call still cannot be made, contact the service provider.

# Index

---

## C

- Configuration Management ..... 7-8
- Configuring Basic IGMP
  - Parameters..... 6-27
- Configuring Basic QoS
  - Parameters..... 6-16
- Configuring Basic TR-069
  - Parameters..... 7-1
- Configuring Basic WLAN
  - Parameters..... 4-5
- Configuring DDNS..... 6-9
- Configuring Default Gateway..... 4-17
- Configuring DHCP Binding ..... 4-14
- Configuring DHCP Server ..... 4-13
- Configuring DMZ Host..... 5-7
- Configuring Domain Name ..... 6-13
- Configuring Fax..... 6-8
- Configuring Firewall..... 5-1
- Configuring FTP Application ..... 6-34
- Configuring Host Name ..... 6-14
- Configuring IP Filter..... 5-2
- Configuring Multi-SSID
  - Parameters..... 4-7
- Configuring Multicast MAC Limit ..... 6-31
- Configuring Multicast VLAN..... 6-30
- Configuring MVLAN Tag Strip..... 6-33
- Configuring Port Forwarding..... 5-8
- Configuring QoS Ingress Rate
  - Limit ..... 6-24
- Configuring QoS Local
  - Application..... 6-21
- Configuring QoS Queue
  - Management ..... 6-22
- Configuring QoS Rule ..... 6-18
- Configuring QoS Rule Type..... 6-19
- Configuring Security Properties ..... 4-8
- Configuring SIP ..... 6-2
- Configuring SNTP Client ..... 6-25
- Configuring Specific Address
  - Range ..... 4-15
- Configuring Static Routing..... 4-18
- Configuring the SIP Accounts..... 6-4
- Configuring UPnP ..... 6-11
- Configuring URL Filter..... 5-5
- Configuring VoIP Advanced
  - Parameters..... 6-5
- Configuring VoIP Media
  - Parameters..... 6-7
- Configuring WAN
  - Connection ..... 4-1, 6-1

## D

- Device Information ..... 3-1

## E

- Ethernet Interface Information ..... 3-4

## F

- Features and Specifications ..... 1-3

## I

- Importing TR-069 Certificate..... 7-3

## L

- Log Management ..... 7-9
- Logging In to the Device..... 2-6

## N

- Network Connection Information..... 3-2

## P

- Packing List..... 1-2
- Ping Diagnosis ..... 7-10
- Preliminary Setup..... 2-1
- Product Appearance..... 1-4

## **S**

Safety Precautions .....	1-1
Software Upgrade .....	7-6
System Application Environment .....	1-7
System Management .....	7-5
System Requirements .....	1-6

## **U**

User Management.....	7-4
----------------------	-----

## **V**

Viewing Associated Devices .....	4-12
VoIP Status Information.....	3-5

## **W**

WLAN Interface Information .....	3-3
----------------------------------	-----

# Glossary

---

**CNG**

- Comfort Noise Generation

**DC**

- Direct Current

**DDNS**

- Dynamic Domain Name Server

**DHCP**

- Dynamic Host Configuration Protocol

**DMZ**

- Demilitarized Zone

**DNAT**

- Destination Network Address Translation

**DNS**

- Domain Name Server

**DSCP**

- Differentiated Services Code Point

**DSL**

- Digital Subscriber Line

**DTMF**

- Dual-Tone Multi-Frequency

**DWRR**

- Deficit Weighted Round Robin

**FTP**

- File Transfer Protocol

**FTTH**

- Fiber to the Home

**GE**

- Gigabit Ethernet

**GPON**

- Gigabit Passive Optical Network

**HTTP**

- Hypertext Transfer Protocol

**ICMP**

- Internet Control Message Protocol

**IEEE**

- Institute of Electrical and Electronics Engineers

**IGMP**

- Internet Group Management Protocol

**IP**

- Internet Protocol

**IPTV**

- Internet Protocol Television

**ISP**

- Internet Service Provider

**ITU**

- International Telecommunications Union

**LAN**

- Local Area Network

**MAC**

- Medium Access Control

**NAT**

- Network Address Translation

**NTP**

- Network Time Protocol

**OLT**

- Optical Line Terminal

**OMCI**

- ONT Management Control Interface

**ONT**

- Optical Network Terminal

**ONU**

- Optical Network Unit

**PON**

- Passive Optical Network

**POTS**

- Plain Old Telephone Service

**PPPoE**

- Point to Point Protocol over Ethernet

**QoS**

- Quality of Service

**RF**

- Radio Frequency

**RTP**

- Real-time Transport Protocol

**SIP**

- Session Initiation Protocol

**SNTP**

- Simple Network Time Protocol

**SP**

- Strict Priority

**SS**

- Soft Switch

**TCP**

- Transfer Control Protocol

**TCP/IP**

- Transfer Control Protocol/Internet Protocol

**UDP**

- User Datagram Protocol

**URL**

- UniformResource Locator

**VAD**

- Voice Activity Detectors

**VLAN**

- Virtual Local Area Network

**VoIP**

- Voice over Internet Protocol

**WAN**

- Wide Area Network

**WEP**

- Wired Equivalent Privacy

**WLAN**

- Wireless Local Area Network

**WPA**

- Wi-Fi Protected Access