

The Smartest Network Device

Quick Installation Guide


Wireless Adapter


Suitable for: A1000UA, A2000UA, A1900PE, A1200PE


V1.0 | 1801


Copyrights © TOTOLINK All rights reserved. Website: <http://www.totolink.net>
Information in this document is subject to change without prior notice.


Instruction of LAN Adapter Driver Installation


- 

Put into the CD
- 

Double-click the CD drive letter, choose the corresponding model NO. with correct system type, then click "Install".
- 


Select **I accept the terms of the license agreement**, and then click **Next**.
- 


Select **Install driver and TOTOLINK WLAN Utility**, and then click the **Next** button.
- 

Click the **Install** button to continue with installation.
- 


The installation is complete. It requires you to restart your computer before using the program.

LAN Adapter Physical Connection Diagram

- 


Plug wireless USB adapter into the PC's USB interface.
- 


- Install adapter**
Insert the adapter in the PCI slot, and secure it.
 - Attach antenna**
Connect the external antenna to the adapter's antenna port





For more information, please visit www.totolink.net.


Windows 10 Wireless Network Configuration


- 

Right-click the Network icon in the taskbar.
- 

Click **Change adapter settings** in the Network and Sharing Center.
- 


Right-click the **WLAN 9** connection and click **Connect / Disconnect**.
- 


Click **Wi-Fi** in the Settings app to turn it on.
- 


Enter the network security key when prompted.
- 


Verify the connection status in the Network and Sharing Center.


Windows 7 Wireless Network Configuration


- 

Right-click the Network icon in the taskbar.
- 

Click **Change adapter settings** in the Network and Sharing Center.
- 

Right-click the **Wireless Network Connection** and click **Connect / Disconnect**.
- 

Click **Connect** in the Connections available window.
- 

Enter the network security key when prompted.
- 

Verify the connection status in the Network and Sharing Center.