

RG-S2910XS-E Series Switches

Hardware Installation and Reference Guide

Copyright

All rights are reserved in this document and this statement.

Any reproduction, excerpt, backup, modification, transmission, translation or commercial use of this document or any portion of this document, in any form or by any means, without the prior written consent of Ruijie Networks is prohibited.

Trademark  and  are owned by Ruijie Networks.

All other trademarks or registered trademarks mentioned in this document are owned by their respective owners.

Disclaimer

The products, services, or features you purchase are subject to commercial contracts and terms. Some or all of the products, services or features described in this document may not be within the scope of your purchase or use. Unless otherwise agreed in the contract, Ruijie Networks does not make any express or implied statement or guarantee for the content of this document.

Due to product version upgrades or other reasons, the content of this document will be updated from time to time. Ruijie Networks reserves the right to modify the content of the document without any notice or prompt.

This manual is for reference only. Ruijie Networks endeavors to ensure content accuracy and will not shoulder any responsibility for losses and damages caused due to content omissions, inaccuracies or errors.

Preface

Intended Audience

This document is intended for:

- Network engineers
- Technical support and service engineers
- Network administrators

Technical Support

- Ruijie Networks website: <https://www.ruijienetworks.com/>
- Technical support website: <https://ruijienetworks.com/support>
- Case portal: <https://caseportal.ruijienetworks.com>
- Community: <https://community.ruijienetworks.com>
- Technical support email: service_rj@ruijienetworks.com
- Skype: [service_rj@ruijienetworks.com](https://www.skype.com/people/service_rj@ruijienetworks.com)

Conventions

1. Signs

The signs used in this document are described as follows:

Warning

An alert that calls attention to important rules and information that if not understood or followed can result in data loss or equipment damage.

Caution

An alert that calls attention to essential information that if not understood or followed can result in function failure or performance degradation.

Note

An alert that contains additional or supplementary information that if not understood or followed will not lead to serious consequences.

Specification

An alert that contains a description of product or version support.

2. Note




The manual offers configuration information (including model, port type and command line interface) for indicative purpose only. In case of any discrepancy or inconsistency between the manual and the actual version, the actual version prevails.

1 Product Overview

The RG-S2910XS-E series switch is a next-generation intelligent switch that features high performance, high security, multiple services and ease of use to meet the needs of the current networks. The RG-S2910XS-E series switch can provide the complete end-to-end Quality of Service (QoS), flexible and abundant security policies and policy-based network management for various networks. It is greatly ideal for such applications as campus network, enterprise network, government network, service network, residential broadband access and business building network, providing high-speed, high-efficiency, secure and intelligent access solutions.

Table 1-1 RG-S2910XS-E


Model	10/100/1000 Base-T Auto-sensing Ethernet Port	SFP+ Port	1000Base-X SFP Port	Console Port	USB Port	Expansion Module Slot	Pluggable Power Slot
RG-S2910-24GT4XS-E	24	4	N/A	1	N/A	N/A	N/A
RG-S2910-48GT4XS-E	48	4	N/A	1	N/A	N/A	N/A
RG-S2910C-24GT2XS-P-E	24 (PoE+)	2	2 (Combo)	1	N/A	1	N/A
RG-S2910C-24GT2XS-HP-E	24 (PoE+)	2	2 (Combo)	1	1(reserved, for future use)	2	Dual
RG-S2910C-48GT2XS-HP-E	48 (PoE+)	2	2 (Combo)	1	1(reserved, for future use)	2	Dual
RG-S2910-24GT4XS-PS-E	24	4	N/A	1	N/A	N/A	N/A


-  The SFP+ ports support both 10Gbase-R and 1000base-X modules.
-  The SFP ports support both 1000base-X and 100base-X modules.
-  1000Base-T is backward compatible with 100Base-TX and 10Base-T.

1.1 RG-S2910-24GT4XS-E

Technical Specifications

Model	RG-S2910-24GT4XS-E
CPU	Single-core CPU with the clock speed of 1.0G
BOOTROM	/
Flash Memory	256MB
SDRAM	DDRIII 512MB
Optical Module	See Appendix B.


	 The supported module type may change at any time. Consult us for the latest information.
SFP+ Port	Supports 10Gbase-R and 1000Base-X SFP+ modules.
Power Supply	<ul style="list-style-type: none"> ● AC input Rated voltage range: 100V to 240V Maximum voltage range: 90V to 264V Frequency: 50/60 Hz Rated current: 1.5A ● HVDC input Voltage range: 192V to 290V Current range: 0.1A to 0.5A
Earth Leakage Current	≤3.5mA
EEE	Supported
PoE	Not supported
Power Consumption	≤24W
Operating Temperature	0°C to 50°C (32°F to 122°F)
Storage Temperature	-40°C to 70°C (-40°F to 158°F)
Operating Humidity	10% to 90% RH
Storage Humidity	5% to 95% RH
Fan	Speed adjustment and fault alarm
Temperature Warning	Supported
EMCStandards	GB/T 9254.1
Security Standards	GB 4943.1
Dimensions (W x D x H)	443mm x 268mm x 44.5mm
Weight	≤3.5kg

 The RG-S2910-24GT4XS-E switch is a class A product. In a domestic environment, this product may cause radio interference in which case the user may be required to take adequate measures.

Product Appearance


The RG-S2910-24GT4XS-E full gigabit Ethernet switch provides 1 RJ45 Console port, 24 RJ45 10/100/1000Base-T auto-sensing Ethernet ports and 4 SFP+ ports on the front panel.

Figure 1-1 Appearance of S2910-24GT4XS-E



Front Panel

Figure1-2 Front Panel of RG-S2910-24GT4XS-E






Note	1. System status LED	4. 10G SFP+ port
	2. Console port	5. 10G SFP+ port
	3. 10/100/1000 Base-T auto-sensing Ethernet port	6. 10/100/1000 Base-T copper port status LED
		7. SFP+ fiber port status LED

Back Panel

Figure 1-3 Back Panel of RG-S2910-24GT4XS-E



Note	1. Grounding pole	3. Power cord retention clips
	2. Three-hole AC power receptacle	

-  This device relies on the separate protective grounding terminal.
-  The device installation shall be permanently connected to building ground by a skilled person.
-  The device shall be intended to be used in a location having equipotential bonding (such as a telecommunication centre, a dedicated computer room, or a restricted access area).

Power Supply

The RG-S2910-24GT4XS-E switch adopts AC or HVDC power input.

- AC input

Rated voltage range: 100V to 240V, 50/60 Hz

Maximum voltage range: 90V to 264V, 47 Hz to 63 Hz

Frequency: 50/60 Hz

Rated current: 1.5A

Power cord specification: 10A

- HVDC input

Voltage range: 192V to 290V

Current range: 0.1A to 0.5A

Heat Dissipation

The RG-S2910-24GT4XS-E full gigabit switch is designed with fans. To ensure good dissipation, sufficient space (10 cm distance from both sides and the back panel of the chassis) should be reserved for ventilation. It is recommended to clean the switch at regular intervals (like once every 3 months). Especially, avoid dust from blocking the screen mesh on the back of the cabinet; otherwise, the temperature of the device may go too high and affects the performance.

Figure 1-4 Flow Scheme of Heat Dissipation



i When installing the device, sufficient ventilation space (1 U (44.45 mm) distance from the adjacent device) should be reserved for the purpose of heat dissipation.

LEDs

LED	Panel Marker	Status	Indication
System status LED	Status	Blinking green	The system is being initialized.
		Solid green	The switch is operational.
		Solid red	<ul style="list-style-type: none"> ● Over-temperature, the system will reboot. ● The switch is faulty.
10/100/1000 Base-T copper port status LED	1-24	Off	The port is not connected.
		Solid green	The port is connected at 1000 Mbps.
		Solid yellow	The port is connected at 10/100 Mbps.
		Blinking	Data are being transceived at the port.
SFP+ fiber port status LED	25F-28F	Off	The port is not connected.
		Solid green	The port is connected.
		Blinking	Data are being transceived at the port.

1.2 RG-S2910-48GT4XS-E

Technical Specifications


Model	RG-S2910-48GT4XS-E
CPU	Single-core CPU with the clock speed of 1.0G
BOOTROM	/
Flash Memory	256MB
SDRAM	DDRIII 512MB
Optical Module	See Appendix B.  The supported module type may change at any time. Consult us for the latest information.
SFP+ Port	Supports 10Gbase-R and 1000Base-X SFP+ modules.
Power Supply	<ul style="list-style-type: none"> ● AC input Rated voltage range: 100V to 240V Maximum voltage range: 90V to 264V Frequency: 50/60 Hz Rated current: 1.5A ● HVDC input Voltage range: 192V to 290V Current range: 0.5A to 0.8A
Earth Leakage Current	≤3.5mA
EEE	Supported
PoE	Not supported
Power Consumption	≤50W
Operating Temperature	0°C to 50°C (32°F to 122°F)
Storage Temperature	-40°C to 70°C (-40°F to 158°F)
Operating Humidity	10% to 90% RH
Storage Humidity	5% to 95% RH
Fan	Speed adjustment and fault alarm
Temperature Warning	Supported
EMC Standards	GB/T 9254.1
Security Standards	GB 4943.1
Dimensions (W x D x H)	443mm x 268mm x 44.5mm
Weight	≤4kg

⚠ The RG-S2910-48GT4XS-E switch is a class A product. In a domestic environment, this product may cause radio interference in which case the user may be required to take adequate measures.

Product Appearance


On the front panel, the RG-S2910-48GT4XS-E full gigabit Ethernet switch provides 1 RJ45 Console port, 48 RJ45 10/100/1000Base-T auto-sensing Ethernet ports and 4 SFP+ ports.

Figure 1-5 Appearance of S2910-48GT4XS-E



Front Panel

Figure1-6 Front Panel of RG-S2910-48GT4XS-E



Note	1. System status LED	5.10G SFP+ port
	2. Console port	6. 10/100/1000 Base-T copper port status LED
	3.10/100/1000 Base-T auto-sensing Ethernet port	7. SFP+ port status LED
	4.10G SFP+ port	

Back Panel

Figure 1-7 Back Panel of RG-S2910-48GT4XS-E



Note	1. Grounding pole	3. Power cord retention clips
	2. Three-hole AC power receptacle	

Power Supply

The RG-S2910-48GT4XS-E switch adopts AC or HVDC power input.

- AC input

Rated voltage range: 100V to 240V, 50/60Hz

Maximum voltage range: 90V to 264V, 47 Hz to 63 Hz

Frequency: 50/60 Hz

Rated current: 1.5A

Power cord specification: 10A

- HVDC input


Voltage range: 192V to 290V

Current range: 0.5A to 0.8A

Heat Dissipation

The RG-S2910-48GT4XS-E full gigabit switch is designed with fans. To ensure good dissipation, sufficient space (10 cm distance from both sides and the back panel of the chassis) should be reserved for ventilation. It is recommended to clean the switch at regular intervals (like once every 3 months). Especially, avoid dust from blocking the screen mesh on the back of the cabinet; otherwise, the temperature of the device may go too high and affects the performance.

Figure 1-8 Flow Scheme of Heat Dissipation






LEDs


LED	Panel Marker	Status	Indication
System status LED	Status	Blinking green	The system is being initialized.
		Solid green	The switch is operational.
		Solid red	<ul style="list-style-type: none"> ● Over-temperature, the system will reboot. ● The switch is faulty.
10/100/1000 Base-T copper port status LED	1-48	Off	The port is not connected.
		Solid green	The port is connected at 1000 Mbps.
		Solid yellow	The port is connected at 10/100 Mbps
		Blinking	Data are being transceived at the port.
SFP+ fiber port status LED	49F-52F	Off	The port is not connected.
		Solid green	The port is connected.
		Blinking	Data are being transceived at the port.

1.3 RG-S2910C-24GT2XS-P-E

Technical Specifications

Model	RG-S2910C-24GT2XS-P-E
CPU	Single-core CPU with the clock speed of 1.0G
BOOTROM	/
Flash Memory	512MB
SDRAM	DDRIII 512MB
Optical Module	See Appendix B.  The supported module type may change at any time. Consult us for the latest information.
Expansion Module	Supports M2900-01XT, M2910-01XS and M2910-02XS modules.
SFP Port	Supports 1000Base-X SFP modules.
SFP+ Port	Supports 10Gbase-R and 1000Base-X SFP+ modules.
Power Supply	<ul style="list-style-type: none"> ● AC input Rated voltage range: 100V to 240V Maximum voltage range: 90V to 264V Frequency: 50/60 Hz Rated current: 6A ● HVDC input Voltage range: 192V to 290V Current range: 2.5A to 3.5A
Earth Leakage Current	≤0.5mA


EEE	Supported
PoE	<p>All the RJ45 ports are PoE-capable with the maximum power output of 30W. The maximum output power of PoE/PoE+ is 370W.</p> <p> The available number of PDs is determined by PSE output power and PD input power in practice.</p> <p> For PoE port, the pinout of the network cable is “1,2,3,6”.</p>
Power Consumption	<p>Less than 39W without extension cards or PoE load Less than 470W with PoE full load</p>
Operating Temperature	0°C to 50°C (32°F to 122°F)
Storage Temperature	-40°C to 70°C (-40°F to 158°F)
Operating Humidity	10% to 90% RH
Storage Humidity	5% to 95% RH
Fan	Speed adjustment and fault alarm
Temperature Warning	Supported
EMC Standards	GB/T 9254.1
Security Standards	GB 4943.1
Dimensions (W x D x H)	440mm x 260mm x 44mm
Weight	5.8kg (with package)

 The RG-S2910C-24GT2XS-P-E switch is a class A product. In a domestic environment, this product may cause radio interference in which case the user may be required to take adequate measures.

Product Appearance


On the front panel, the RG-S2910C-24GT2XS-P-E Ethernet switch provides 24 10/100/1000Base-T Ethernet ports, 2 GE SFP fiber/copper combo ports, 2 10G SFP+ ports and 1 Console port. On the back panel, it provides AC power ports and 1 expansion module slot.

Figure 1-9 Appearance of RG-S2910C-24GT2XS-P-E



Front Panel

Figure 1-10 Front Panel of RG-S2910C-24GT2XS-P-E




- Note:
- | | |
|--------------------------------|---|
| 1. System status LED | 6. PoE mode switch-over button |
| 2. Expansion module status LED | 7. Console port |
| 3. PoE status LED | 8. 10/100/1000Base-T auto-sensing Ethernet port |
| 4. Copper port status LED | 9. 1000Base-X SFP port |
| 5. Fiber port status LED | 10. SFP+ port |

⚠ Long press PoE Mode Switch-Over Button for above 2 seconds to switch the display mode between PoE mode and port rate mode.

Back Panel

Figure 1-11 Back Panel of RG-S2910C-24GT2XS-P-E



Note: 1. Grounding pole 2. Expansion module slot

Power Supply

The RG-S2910C-24GT2XS-P-E switch adopts AC or HVDC power input.

- AC input

Rated voltage range: 100V to 240V

Maximum voltage range: 90V to 264V

Frequency range: 50/60 Hz

Rated current: 6A

Power cord specification: 10A

- HVDC input


Voltage range: 192V to 290V

Current range: 2.5A to 3.5A

Heat Dissipation

The RG-S2910C-24GT2XS-P-E adopts turbine fans for heat dissipation, thereby ensuring normal function of the device in the specified environment. 10 cm distance space should be reserved at both sides and the back plane of the cabinet to allow air circulation. It is recommended to clean the device once every 3 months to avoid dust from blocking vents. Figure 1-12 shows the flow scheme of heat dissipation.

Figure 1-12 Flow Scheme of Heat Dissipation




LEDs



LED	Panel Identification	State	Meaning
System status LED	Status	Off	The switch is not receiving power.
		Blinking green	The system is being initialized. Continuous blinking indicates errors.
		Solid green	The switch is operational.
		Solid yellow	Temperature warning Check the working environment of the switch immediately.
		Solid red	The switch is faulty.
Expansion module status LED	Mod	Off	There is no expansion module or the expansion module is not correctly installed.
		Solid green	The expansion module is correctly installed.


PoE status LED	PoE	Solid green	Indicates the switching state.
		Solid yellow	Indicates the PoE state.
1000Mbps RJ-45 port status LED	1-24	Off	The port is not connected.
		Solid green	The port is connected at 1000 Mbps.
		Blinking green	The port is receiving or transmitting traffic at 1000 Mbps.
		Solid yellow	The port is connected at 10/100 Mbps.
		Blinking yellow	The port is receiving or transmitting traffic at 10/100 Mbps.
RJ45 port PoE status LED	1-24	Off	PoE is not enabled.
		Solid green	PoE is enabled. The port is operational.
		Solid yellow	The port has a PoE fault of overload.
1000Mbps SFP port status LED	23F-24F	Off	The port is not connected.
		Solid green	The port is connected at 1000 Mbps.
		Blinking green	The port is receiving or transmitting traffic at 1000 Mbps.
		Solid yellow	The port is connected at 100 Mbps.
		Blinking yellow	The port is receiving or transmitting traffic at 100 Mbps.
SFP+ port status LED	25F-26F	Off	The port is not connected.
		Solid green	The port is connected.
		Blinking green	The port is receiving or transmitting traffic at 1000 Mbps.

1.4 RG-S2910C-24GT2XS-HP-E

Technical Specifications

Model	RG-S2910C-24GT2XS-HP-E
CPU	Single-core CPU with the clock speed of 1.0G
BOOTROM	/
Flash Memory	512MB
SDRAM	DDRIII 512MB
Optical Module	See Appendix B.  The supported module type may change at any time. Consult us for the latest information.
Expansion Module	Supports M2910-01XT and M2910-01XS modules.
SFP Port	Supports 1000Base-X SFP modules.
SFP+ Port	Supports 10Gbase-R and 1000Base-X SFP+ modules.
RPS Type	Dual power supplies
Power Supply	<ul style="list-style-type: none"> ● RG- M5000E-AC500P <ol style="list-style-type: none"> 1) AC <p>Rated voltage range: 100V to 240V</p> <p>Rated current range: 3.5A to 7A</p> <p>Frequency range: 50/60 Hz</p> 2) HVDC <p>Voltage range: 192 V to 290V</p> <p>Rated current range: 2.5 A to 3.5 A</p> ● RG-PA1150P-F <ol style="list-style-type: none"> 1) AC <p>Rated voltage range: 100V to 240V</p> <p>Frequency range: 50/60 Hz</p> <p>Rated current: 10A</p> 2) HVDC <p>Voltage range: 192V to 290V</p> <p>Rated current: 10A</p> ● RG-M5000E-DC500P (DC) <p>Voltage range: -72V to -36V</p> <p>Rated current: 16.5 A</p>


Earth Leakage Current	≤3.5mA
EEE	Supported
PoE	<p>All the RJ45 ports are PoE-capable with the maximum power output of 30W.</p> <p> The available number of PDs is determined by PSE output power and PD input power in practice.</p> <p> For PoE port, the pinout of the network cable is “1,2,3,6”.</p>
Power Consumption	<p>Less than 38W without extension cards or PoE load</p> <p>Less than 850W with PoE full load</p>
Operating Temperature	0°C to 50°C (32°F to 122°F)
Storage Temperature	-40°C to 70°C (-40°F to 158°F)
Operating Humidity	10% to 90% RH
Storage Humidity	5% to 95% RH
Fan	Speed adjustment and fault alarm
Temperature Warning	Supported
EMC Standards	GB/T 9254.1
Security Standards	GB 4943.1
Dimensions (W x D x H)	440 mm x 320 mm x 44 mm (The depth is 410 mm when the RG-PA1150P-F power supply module is in use. You are advised to install the device in a cabinet with a depth of at least 800 mm.)
Weight	5.8kg (with package)

 The RG-S2910C-24GT2XS-HP-E switch is a class A product. In a domestic environment, this product may cause radio interference in which case the user may be required to take adequate measures.

Product Appearance


On the front panel, the RG-S2910C-24GT2XS-HP-E Ethernet switch provides 24 10/100/1000Base-T Ethernet ports, 2 GE SFP fiber/copper combo ports, 2 10G SFP+ ports and 1 Console port. On the back panel, it provides 2 power module slots and 2 expansion module slots.

Figure 1-13 Appearance of RG-S2910C-24GT2XS-HP-E



Front Panel

Figure 1-14 Front Panel of RG-S2910C-24GT2XS-HP-E




Note

- | | |
|----------------------------------|--|
| 1. Switch status LED | 8. Fiber port status LED |
| 2. Expansion module 1 status LED | 9. PoE mode switch-over button |
| 3. Expansion module 2 status LED | 10. Console port |
| 4. Power module 1 status LED | 11. USB port (reserved, for future use) |
| 5. Power module 2 status LED | 12. 10/100/1000Base-T auto-sensing Ethernet port |
| 6. PoE status LED | 13. 1000Base-X SFP port |
| 7. Copper port status LED | 14. SFP+ port |

! Long press PoE Mode Switch-Over Button for above 2 seconds to switch the display mode between PoE mode and port rate mode.

Back Panel

Figure 1-15 Back Panel of RG-S2910C-24GT2XS-HP-E



Note:

- | | | | |
|----|-------------------------|----|---------------------|
| 1. | Expansion module 1 slot | 4. | Power module 2 slot |
| 2. | Expansion module 2 slot | 5. | Grounding pole |
| 3. | Power module 1 slot | | |

Power Supply

The RG-S2910C-24GT2XS-HP-E supports 2 power modules with AC or DC input. For the detailed power specification, see the following tables.

Model	RG-M5000E-AC500P	RG-M5000E-AC500P (HVDC)
Platform	RG-S2910C-24GT2XS-HP-E RG-S2910C-48GT2XS-HP-E	RG-S2910C-24GT2XS-HP-E RG-S2910C-48GT2XS-HP-E
Rated Voltage Range	100V to 240V 50/60 Hz	240V
Maximum Voltage Range	90 V to 264 V 50/60 Hz	192V to 290V
PoE Power	Single power supply: 370W Dual power supplies: 740W	
Hot Swapping	Supported	
Redundant Power Supplies	1+1	
Over-Voltage Protection	54 V: -60V to -57V 12 V: 13.4V to 16V	
Over-Current	54V: 8A to 10A	

Protection	12V: 12A to 16A
Over-Temperature Protection	Supported
Load-Balanced Power Supply	Supported
Power Supply Mix	Supported with RG-M5000E-DC500P
Power Cord	10A
Dimensions (W x D x H)	224.5 mm x 90 mm x 40 mm (with connecting fingers and handles) 195.4 mm x 90 mm x 40 mm (without connecting fingers or handles)
Weight	1.6kg

Model	RG-M5000E-DC500P
Platform	RG-S2910C-24GT2XS-HP-E RG-S2910C-48GT2XS-HP-E
Rated Voltage Range	-72V to -36V
PoE Power	Single power supply: 370 W Dual power supplies: 740 W
Hot Swapping	Supported
Redundant Power Supplies	1+1
Over-Voltage Protection	54 V: -66V to -58V 12 V: 13.2V to 15.6V
Over-Current Protection	54V: 7.8A to 10A 12 V: 11A to 14A
Over-Temperature	Supported

Protection	
Load-Balanced Power Supply	Supported
Power Supply Mix	Supported with RG-M5000E-AC500P
Power Cord	PD650I (DC)
Dimensions (W x D x H)	224.5 mm x 90 mm x 43.2 mm (with connecting fingers and handles) 195.4 mm x 90 mm x 43.2 mm (without connecting fingers or handles)
Weight	1.6kg

Model	RG-PA1150P-F	RG-PA1150P-F (HVDC)
Platform	RG-S2910C-24GT2XS-HP-E RG-S2910C-48GT2XS-HP-E	RG-S2910C-24GT2XS-HP-E RG-S2910C-48GT2XS-HP-E
Rated Voltage Range	100V to 240V 50/60 Hz	240V
Maximum Voltage Range	90V to 264V 50/60 Hz	192V to 290V
PoE Power	<ul style="list-style-type: none"> ● 175 V to 240 V input: Single power supply: 740 W Dual power supplies: 1480 W ● 90 V to 175 V input: Single power supply: 370 W Dual power supplies: 740 W 	
Hot Swapping	Supported	
Redundant Power Supplies	1+1 (The overall PoE load is less than 740W when 175 V to 240 V power input applies.)	

Over-Voltage Protection	54V: -60V to -57V 12V: 14V to 16V
Over-Current Protection	54V: 16.5A to 20A 12V: 32A to 40A
Over-Temperature Protection	Supported
Load-Balanced Power Supply	Supported
Power Supply Mix	Not supported
Power Chord	10A
Dimensions (W x D x H)	301 mm x 90 mm x 40 mm (with connecting fingers and handles) 281 mm x 90 mm x 40 mm (without connecting fingers or handles)
Weight	1.6kg

Dual-power input: The switch can be powered by one power module, or two power modules. When both two modules are available, the switch is powered in load-balanced state.




When the switch is powered by the dual-power modules, if the system working power is greater than the capacity of single power module, power redundancy cannot work.

Heat Dissipation

The RG-S2910C-24GT2XS-HP-E adopts turbine fans for heat dissipation, thereby ensuring normal function of the device in the specified environment. 10 cm distance space should be reserved at both sides and the back plane of the cabinet to allow air circulation. It is recommended to clean the device once every 3 months to avoid dust from blocking vents. Figure 1-16 shows the flow scheme of heat dissipation.

Figure 1-16 Flow Scheme of Heat Dissipation



LEDs


LED	Panel Identification	State	Meaning
System status LED	Status	Off	The switch is not receiving power.
		Blinking green	The system is being initialized. Continuous blinking indicates errors.
		Solid green	The switch is operational.
		Solid yellow	Temperature warning Check the working environment of the switch immediately.
		Solid red	The switch is faulty.
Expansion module status LED	M1/M2	Off	There is no expansion module or the expansion module is not correctly installed.



		Solid green	The expansion module is correctly installed.
Power module status LED	PWR1/PWR2	Off	The power module is not in place.
		Solid red	The power module is in place but the AC power cord or switch is abnormal.
		Solid green	The power supply is operational.
PoE status LED	PoE	Solid green	Indicates the switching state.
		Solid yellow	Indicates the PoE state.
1000Mbps RJ-45 port status LED	1-24	Off	The port is not connected.
		Solid green	The port is connected at 1000 Mbps.
		Blinking green	The port is receiving or transmitting traffic at 1000 Mbps.
		Solid yellow	The port is connected at 10/100 Mbps.
		Blinking yellow	The port is receiving or transmitting traffic at 10/100 Mbps.
RJ45 port PoE status LED	1-24	Off	PoE is not enabled.
		Solid green	PoE is enabled. The port is operational.
		Solid yellow	The port has a PoE fault of overload.
1000Mbps SFP port status LED	23F-24F	Off	The port is not connected.
		Solid green	The port is connected at 1000 Mbps.
		Blinking green	The port is receiving or transmitting traffic at 1000 Mbps.
		Solid yellow	The port is connected at 100 Mbps.
		Blinking yellow	The port is receiving or transmitting traffic at 100 Mbps.


SFP+ port status LED	25F-26F	Off	The port is not connected.
		Solid green	The port is connected.
		Blinking green	The port is receiving or transmitting traffic at 1000 Mbps.

1.5 RG-S2910C-48GT2XS-HP-E

Technical Specifications

Model	RG-S2910C-48GT2XS-HP-E
CPU	Single-core CPU with the clock speed of 1.0G
BOOTROM	/
Flash Memory	512MB
SDRAM	DDRIII 512MB
Optical Module	See Appendix B.  The supported module type may change at any time. Consult us for the latest information.
Expansion Module	Supports M2910-01XT and M2910-01XS modules.
SFP Port	Supports 1000Base-X SFP modules.
SFP+ Port	Supports 10Gbase-R and 1000Base-X SFP+ modules.
RPS Type	Dual power supplies
Power Supply	<ul style="list-style-type: none"> ● RG-M5000E-AC500P <ol style="list-style-type: none"> 1) AC <p>Rated voltage range: 100V to 240V</p> <p>Rated current range: 3.5A to 7A</p> <p>Frequency range: 50/60 Hz</p> 2) HVDC <p>Rated voltage range: 192V to 290V</p> <p>Rated current range: 2.5A to 3.5A</p> <ul style="list-style-type: none"> ● RG-PA1150P-F <ol style="list-style-type: none"> 1) AC <p>Rated voltage range: 100V to 240V</p> <p>Frequency range: 50/60 Hz</p>


	<p>Rated current: 10A</p> <p>2) HVDC</p> <p>Rated voltage range: 192V to 290V</p> <p>Rated current: 10A</p> <ul style="list-style-type: none"> ● M5000E-DC500P (DC) <p>Rated voltage range: -72V to -36V</p> <p>Rated current:16.5A</p>
Earth Leakage Current	≤3.5mA
EEE	Supported
PoE	<p>All the RJ45 ports are PoE-capable with the maximum power output of 30W.</p> <p> The available number of PDs is determined by PSE output power and PD input power in practice.</p> <p> For PoE port, the pinout of the network cable is “1,2,3,6”.</p>
Power Consumption	<p>Less than 57W without extension cards or PoE load</p> <p>Less than 1,700W with PoE full load</p>
Operating Temperature	0°C to 50°C (32°F to 122°F)
Storage Temperature	-40°C to 70°C (-40°F to 158°F)
Operating Humidity	10% to 90% RH
Storage Humidity	5% to 95% RH
Fan	Speed adjustment and fault alarm
Temperature Warning	Supported
EMC Standards	GB/T 9254.1
Security Standards	GB 4943.1
Dimensions (W x D x H)	440 mm x 320 mm x 44 mm (The depth is 410 mm when the RG-PA1150P-F power supply module is in use. You are advised to install the device in a cabinet with a depth of at least 800 mm.)
Weight	6.8kg (with package)

 The RG-S2910C-48GT2XS-HP-E switch is a class A product. In a domestic environment, this product may cause radio interference in which case the user may be required to take adequate measures.

Product Appearance


On the front panel, the RG-S2910C-48GT2XS-HP-E Ethernet switch provides 48 10/100/1000Base-T Ethernet ports, 2 GE SFP fiber/copper combo ports, 2 10G SFP+ ports and 1 Console port. On the back panel, it provides 2 power module slots and 2 expansion module slots.

Figure 1-17 Appearance of RG-S2910C-48GT2XS-HP-E



Front Panel

Figure 1-18 Front Panel of RG-S2910C-48GT2XS-HP-E




Note:	1. System status LED	8. Fiber port status LED
	2. Expansion module 1 status LED	9. PoE mode switch-over button
	3. Expansion module 2 status LED	10. Console port
	4. Power module 1 status LED	11. USB port (reserved, for future use)
	5. Power module 2 status LED	12. 10/100/1000Base-T auto-sensing Ethernet port
	6. PoE status LED	13. 1000Base-X SFP port
	7. Copper port status LED	14. SFP+ port

! Long press PoE Mode Switch-Over Button for above 2 seconds to switch the display mode between PoE mode and port rate mode.

Back Panel

Figure 1-19 Back Panel of RG-S2910C-48GT2XS-HP-E



Note:

- | | |
|----------------------------|------------------------|
| 1. Expansion module 1 slot | 4. Power module 2 slot |
| 2. Expansion module 2 slot | 5. Grounding pole |
| 3. Power module 1 slot | |

Power Supply

The RG-S2910C-48GT2XS-HP-E supports two power modules with AC or DC input. For the detailed power specification, see the section of *Power Supply* for RG-S2910C-48GT2XS-HP-E.

Dual-power input: The switch can be powered by one power module, or by two power modules. When both two modules are available, the switch is powered in the load-balanced mode.


⚠ When the switch is powered by the dual-power modules, if the system working power is greater than the capacity of single power module, the power redundancy cannot work.

Heat Dissipation

The RG-S2910C-48GT2XS-HP-E adopts turbine fans for heat dissipation, thereby ensuring normal function of the device in the specified environment. 10 cm distance space should be reserved at both sides and the back plane of the cabinet to allow air circulation. It is recommended to clean the device once every 3 months to prevent dust from blocking vents.

Figure 1-20 shows the flow scheme of heat dissipation.

Figure 1-20 Flow Scheme of Heat Dissipation



LEDs


LED	Panel Identification	State	Meaning
System status LED	Status	Off	The switch is not receiving power.
		Blinking green	The system is being initialized. Continuous blinking indicates errors.
		Solid green	The switch is operational.
		Solid yellow	Temperature warning Check the working environment of the switch immediately.
		Solid red	The switch is faulty.

Expansion module status LED	M1/M2	Off	There is no expansion module or the expansion module is not correctly installed.
		Solid green	The expansion module is correctly installed.
Power module status LED	PWR1/PWR2	Off	The power module is not in place.
		Solid red	The power module is in place but the AC power chord or switch is abnormal.
		Solid green	The power supply is normal.
PoE status LED	PoE	Solid green	Indicates the switching state.
		Solid yellow	Indicates the PoE state.
1000Mbps RJ-45 port status LED	1-24	Off	The port is not connected.
		Solid green	The port is connected at 1000 Mbps.
		Blinking green	The port is receiving or transmitting traffic at 1000 Mbps.
		Solid yellow	The port is connected at 10/100 Mbps.
		Blinking yellow	The port is receiving or transmitting traffic at 10/100 Mbps.
RJ45 port PoE status LED	1-48	Off	PoE is not enabled.
		Solid green	PoE is enabled. The port is operational.
		Solid yellow	The port has a PoE fault of overload.
1000Mbps SFP port status LED	47F-48F	Off	The port is not connected.
		Solid green	The port is connected at 1000 Mbps.
		Blinking green	The port is receiving or transmitting traffic at 1000 Mbps.
		Solid yellow	The port is connected at 100 Mbps.

		Blinking yellow	The port is receiving or transmitting traffic at 100 Mbps.
SFP+ port status LED	49F-50F	Off	The port is not connected.
		Solid green	The port is connected
		Blinking green	The port is receiving or transmitting traffic at 1000 Mbps.

1.6 RG-S2910-24GT4XS-PS-E

Technical Specifications

Model	RG-S2910-24GT4XS-PS-E
CPU	Single-core CPU with the clock speed of 1.0G
BOOTROM	/
Flash Memory	256MB
SDRAM	DDRIII 512MB
Optical Module	See Appendix B.  The supported module type may change at any time. Consult us for the latest information.
SFP+ Port	Supports 10Gbase-R and 1000Base-X SFP+ modules.
Power Supply	<ul style="list-style-type: none"> ● AC input Rated voltage range: 100V to 240V Maximum voltage range: 90V to 264V Frequency range: 50/60 Hz Rated current: 5.6A
Earth Leakage Current	≤2.5mA
EEE	Supported
PoE	Not supported
Power Consumption	Less than 23W
Operating Temperature	0°C to 50°C (32°F to 122°F)
Storage Temperature	-40°C to 70°C (-40°F to 158°F)
Operating Humidity	10% to 90% RH
Storage Humidity	5% to 95% RH
Fan	Speed adjustment and fault alarm
Temperature	Supported


Warning	
EMC Standards	GB/T 9254.1
Security Standards	GB 4943.1
Dimensions (W x D x H)	440mm x 200mm x 43.6mm
Weight	≤ 3.5kg

! The RG-S2910-24GT4XS-PS-E switch is a class A product. In a domestic environment, this product may cause radio interference in which case the user may be required to take adequate measures.

Product Appearance


On the front panel, the RG-S2910-24GT4XS-PS-E Ethernet switch provides 1 Console port, 24 10/100/1000Base-T Ethernet ports, 4 SFP+ ports and 1 Reset button. On the back panel, it provides 1 AC power port and 2 PowerShare ports.

Figure 1-21 Appearance of RG-S2910-24GT4XS-PS-E



Front Panel

Figure 1-22 Front Panel of RG-S2910-24GT4XS-PS-E




Note:	1. System status LED	5. Reset button
	2. PowerShare status LED	6. Console port
	3. 10/100/1000Base-T copper port status LED	7. 10/100/1000Base-T auto-sensing Ethernet port
	4. SFP+ fiber port status LED	8. 10G SFP+ port

⚠ Press the Reset button for less than 5s to collect system logs. Press the Reset button for 5s or more to collect system logs and then reboot the device.

Back Panel

Figure 1-23 Back Panel of RG-S2910-24GT4XS-PS-E



Note:	1. Grounding pole	4. PowerShare port 2
	2. Power cord retention clips	5. 3-pin AC power port
	3. PowerShare port 1	6. Heat dissipation hole

Power Supply

The RG-S2910-24GT4XS-PS-E switch adopts AC power input. Plus, PowerShare ports are provided.

- AC input

Rated voltage range: 100V to 240V, 50/60Hz

Maximum voltage range: 90V to 264V, 47Hz to 63Hz

Frequency range: 50/60 Hz

Rated current: 5.6A

Power cord specification: 10A

- Power Share

Voltage range: 12VDC


Current range: 0A to 4A

i There are 0.5/3/10m power sharing cables for your choice. Use one power sharing cable to connect two S2910-24GT4XS-PS-E switches. If the local power supply of Switch A is disconnected but that of Switch B remains connected, Switch B provides 12V DC voltage to Switch A via the power sharing cable. In this way, Switch A is able to continue its operation. Power sharing is also supported among three S2910-24GT4XS-PS-E switches. If the local power supply of one or two switches is disconnected, none of the three switches are affected.

Heat Dissipation

The RG-S2910-24GT4XS-PS-E adopts turbine fans for heat dissipation, thereby ensuring normal function of the device in the specified environment. 10 cm distance space should be reserved at both sides and the back plane of the cabinet to allow air circulation. It is recommended to clean the device once every 3 months to avoid dust from blocking vents. Figure 1-24 shows the flow scheme of heat dissipation.

Figure 1-24 Flow Scheme of Heat Dissipation



LEDs

LED	Panel Identification	State	Meaning
System status LED	Status	Off	The switch is not receiving power.
		Blinking green	The system is being initialized. Continuous blinking indicates errors.
		Solid green	The switch is operational.

		Solid yellow	Temperature warning Check the working environment of the switch immediately.
		Solid red	The switch is faulty.
PowerShare status LED	PS	Off	The switch is not receiving power.
		Solid green	The switch is receiving local power supply.
		Solid yellow	The switch is receiving PowerShare power supply.
1000Mbps RJ-45 port status LED	1-24	Off	The port is not connected.
		Solid green	The port is connected at 1000 Mbps.
		Blinking green	The port is receiving or transmitting traffic at 1000 Mbps.
		Solid yellow	The port is connected at 10/100 Mbps.
		Blinking yellow	The port is receiving or transmitting traffic at 10/100 Mbps.
SFP+ port status LED	25F-28F	Off	The port is not connected.
		Solid green	The port is connected.
		Blinking green	The port is receiving or transmitting traffic.

1.7 M2910 Expansion Modules

The RG-S2910-24GT2XS-P-E, RG-S2910C-24GT2XS-HP-E and RG-S2910C-48GT2XS-HP-E switches supports M2910-01XS, M2910-01XT and M2910-02XS modules.


- M2910-01XT provides 1 10Gbase-T Ethernet ports.
- M2910-01XS/2XS provides 1/2 10G SFP+ ports and supports 10GBase-SR/LR/LRM modes. Multiple Ruijie optical modules are available for different transmission distances. Applied to RG-S2910XS-E series switches, this module supports 1-/3-/5-meter SFP+ passive copper cables and Ruijie copper modules involving XG-SFP-CU1M, XG-SFP-CU3M, and XG-SFP-CU5M.

Model	Description	External Port
M2910-01XT	1-port 10G copper module	1 10GBASE-T auto-sensing Ethernet port
M2910-01XS	1-port SFP+ module	1 SFP+ port
M2910-02XS	2-port SFP+ module	2 SFP+ ports

 For the detailed information about the supported modules, please refer to *Switch Expansion module Usage Guide*.

2 Preparation before Installation

2.1 Safety Suggestions

-
-  To avoid personal injury and equipment damage, please carefully read the safety suggestions before you install the RG-S2910XS-E series switch.

The following safety suggestions do not cover all possible dangers.

2.1.1 Installation


- Keep the chassis clean and free from any dust.
- Do not place the equipment in a walking area.
- Do not wear loose clothes or accessories that may be hooked or caught by the device during installation and maintenance.
- Turn off all power supplies and remove the power sockets and cables before installing or uninstalling the device.

2.1.2 Movement


- Do not frequently move the device.
- When moving the device, note the balance and avoid hurting legs and feet or straining the back.
- Before moving the device, turn off all power supplies and dismantle all power modules.




2.1.3 Electricity

- Observe local regulations and specifications when performing electric operations. Relevant operators must be qualified.
- Before installing the device, carefully check any potential danger in the surroundings, such as ungrounded power supply, and damp/wet ground or floor.
- Before installing the device, find out the location of the emergency power supply switch in the room. First cut off the power supply in the case of an accident.
- Try to avoid maintaining the switch that is powered-on alone.
- Be sure to make a careful check before you shut down the power supply.
- Do not place the equipment in a damp location. Do not let any liquid enter the chassis.

 Any nonstandard and inaccurate electric operation may cause an accident such as fire or electrical shock, thus causing severe even fatal damages to human bodies and equipment.

 Direct or indirect touch through a wet object on high-voltage and mains supply may bring a fatal danger.

 For RG-S2910C-24GT2XS-HP-E and RG-S2910C-48GT2XS-HP-E switches have more than one power cords, make sure to cut off all before shut down the system.

-
-  If a power supply system is equipped with a leakage protector (also referred to as "leakage current switch" or "leakage current breaker"), the rated leakage action current of each leakage protector is greater than twice of the theoretical maximum leakage current of all the power supplies in the system. For example, if a system is equipped with sixteen identical power supplies, the leakage current of each power supply is equal to or less than 3.5mA, and the leakage current of the system totals 56mA. A leakage protector with 30mA rated action current supports less than five power supplies (that is, Action current of the leakage protector/2/Maximum leakage current of each power supply = $30/2/3.5 \approx 4.28$). In other words, the leakage protector with 30mA rated action current supports no more than four power supplies. In this case, the sixteen power supplies in the system require at least four leakage protectors with 30mA rated action current and each leakage protector supports four power supplies. If power supplies in a system differ in models, the rated leakage action current of each leakage protector divided by two is greater than the sum of maximum leakage current of all the power supplies. The rated leakage non-action current of a leakage protector shall be 50% of the leakage action current. Take a leakage protector with 30mA rated leakage action current as an example. The rated leakage non-action current shall be 15mA. When the leakage current is below 15mA, the protector shall not act. Otherwise, misoperation may easily occur due to high sensitivity and thus the leakage protector trips, devices are powered off, and services are interrupted.
-  To guarantee personal safety, the rated leakage action current of each leakage protector in the system must be equal to or less than 30mA (human body safety current is 30mA). When twice of the total leakage current of the system is greater than 30mA, the system must be equipped with two or more leakage protectors.
-  For the leakage current value of each power supply model, see the power supply model parameter table in Chapter 1.
-

2.1.4 Static Discharge Damage Prevention

To prevent damage from static electricity, pay attention to the following:

- Proper grounding of grounding screws on the back panel of the device. Use of a three-wire single-phase socket with protective earth wire (PE) as the AC power socket.
- Indoor dust prevention
- Proper humidity conditions

2.1.5 Laser

The RG-S2910XS-E series switch supports varying models of optical modules sold on the market which are Class I laser products. Improper use of optical modules may cause damage. Therefore, pay attention to the following when you use them:

- When a fiber transceiver works, ensure that the port has been connected with an optical fiber or is covered with a dust cap, to keep out dust and avoid burning your eyes.
- When the optical module is working, do not pull out the fiber cable and stare into the transceiver interface or you may hurt your eyes.

 Do not stare into any optical port under any circumstances, as this may cause permanent damage to your eyes.

2.2 Installation Site Requirements

To ensure the normal working and a prolonged durable life of the equipment, the installation site must meet the following requirements.

2.2.1 Ventilation

For the RG-2910XS-E, a sufficient space (at least 10 cm distances from both sides and the back plane of the cabinet) should be reserved at the ventilation openings to ensure the normal ventilation. After various cables have been connected, they should be arranged into bundles or placed on the cabling rack to avoid blocking the air inlets. It is recommended to clean the switch at regular intervals (like once every 3 months). Especially, avoid dust from blocking the screen mesh on the back of the cabinet.

2.2.2 Temperature and Humidity

To ensure the normal operation and prolong the service life of RG-S2910XS-E series switch, you should keep proper temperature and humidity in the equipment room.

If the equipment room has temperature and humidity that do not meet the requirements for a long time, the equipment may be damaged.

- In an environment with high relative humidity, the insulating material may have bad insulation or even leak electricity. Sometimes the materials may suffer from mechanical performance change and metallic parts may get rusted.
- In an environment with low relative humidity, however, the insulating strip may dry and shrink. Static electricity may occur easily and endanger the circuit on the equipment.
- In an environment with high temperature, the equipment is subject to even greater harm, as its performance may degrade significantly and various hardware faults may occur.

Therefore, the ambient temperature and humidity of the RG-S2910XS-E series must meet the requirements listed in Table 2-1:

Table 2-1 Temperature and Humidity Requirements of the RG-S2910XS-E Series Switch

Temperature	Relative Humidity
0 °C to 50°C (32°F to 122°F)	10% to 90%

i The requirements for the sampling site of the temperature and humidity in the operating environment of the device are as follows:

There is no protective plate at the front or back of the equipment rack.

The vertical height is 1.5 m above the floor.

The distance from the front panel of the equipment is 0.4 m.

2.2.3 Cleanness

Dust poses a severe threat to the running of the equipment. The indoor dust falling on the equipment may be adhered by the static electricity, causing bad contact of the metallic joint. Such electrostatic adherence may occur more easily when the relative humidity is low, not only affecting the useful life of the equipment, but also causing communication faults.

Table 2-2 shows the requirements for the dust content and granularity in the equipment room.


Table 2-2 Requirements for the Dust Content and Granularity in the Equipment Room

Dust	Unit	Density
Diameter≥0.5μm	Particles/m ³	≤3.5×10 ⁶
Diameter≥5μm	Particles/m ³	≤3×10 ⁴

Apart from dust, the salt, acid and sulfide in the air in the equipment room must also meet strict requirements, as such poisonous substances may accelerate the corrosion of the metal and the aging of some parts. The equipment room should be protected from the intrusion of harmful gases such as sulfur dioxide, sulfured hydrogen, nitrogen dioxide, and chlorine), whose requirements are listed in Table 2-3.


Table 2-3 Requirements for Harmful Gases in the Equipment Room

Gas	Average (mg/m3)	Maximum (mg/m3)
SO ₂	0.3	1.0
H ₂ S	0.1	0.5
NO ₂	0.5	1.0
Cl ₂	0.1	0.3

 Both average and maximum value are measured for a week. The switch cannot be placed in the environment with the maximum density for over 30 minutes every day.







2.2.4 Grounding

A good grounding system is the basis for the stable and reliable operation of the RG-S2910XS-E series switch. It is the chief condition to prevent lightning stroke and resist interference. Please carefully check the grounding conditions on the installation site according to the grounding requirements, and perform grounding operations properly as required.

 Effective grounding of the switch is an important guarantee for lightning protection and interference resistance. Therefore, connect the grounding line of the switch properly.

Safety Grounding

The equipment using AC power supply must be grounded by using the yellow/green safety grounding cable. Otherwise, when the insulating resistance decreases the power supply and the enclosure in the equipment, electric shock may occur.

-  The building must provide protective grounding connection to ensure that the device is connected to the protection location.
-  The installation and maintenance personnel must check whether the A.C. socket is well connected to the protection location of the building, if not, they should use a protective grounding wire to connect the grounding end of the A.C. socket to the building's protection location.
-  The power supply socket must be installed in a place that is near to the device and where users can operate the device easily.
-  Before the installation of the device, make sure that ground connection is connected at first and disconnected finally.
-  The sectional area of the protective grounding wire should be at least 0.75 mm² (18 AWG).
-  Use the 3-core power supply line. The sectional area of each pin should be at least 0.75 mm² or 18 AWG.


Lightning Grounding

The lightning protection system of a facility is an independent system that consists of the lightning rod, downlead conductor and the connector to the grounding system, which usually shares the power reference ground and yellow/green safety cable ground. The lightning discharge ground is for the facility only, irrelevant to the equipment.

EMC Grounding

The grounding required for EMC design includes shielding ground, filter ground, noise and interference suppression, and level reference. All the above constitute the comprehensive grounding requirements. The resistance of earth wires should be less than 1 ohm. The RG-S2910XS-E series switch back plane is reserved with one grounding pole, as shown in Figure 2-1.

Figure 2-1 Grounding of RG-S2910XS-E



2.2.5 Lightning Resistance

When the AC power cable is imported outdoors and directly connected to the power port of the RG-S2910XS-E series switch, lightning line bank should be adopted to prevent the switch from being hit by lightning shocks. Usage of the lightning line bank: Connect the mains supply AC cable to the lightning line bank. Then, connect the switch to the lightning line bank. This can help to prevent the current of high-voltage lightning from passing the switch directly through the mains supply cable to a certain extent.

- i The lightning line banks are not provided and should be purchased by users as required. For the usage of lightning line banks, refer to their related manuals.

2.2.6 EMI

Electro-Magnetic Interference (EMI), from either outside or inside the equipment or application system, affects the system in the conductive ways such as capacitive coupling, inductive coupling, and electromagnetic radiation.

There are two types of electromagnetic interference: radiated interference and conducted interference, depending on the type of the transmission path.

When the energy, often RF energy, from a component arrives at a sensitive component via the space, the energy is known as radiated interference. The interference source can be either a part of the interfered system or a completely electrically isolated unit. Conducted interference results from the electromagnetic wire or signal cable connection between the source and the sensitive component, along which cable the interference conducts from one unit to another. Conducted interference often affects the power supply of the equipment, but can be controlled by a filter. Radiated interference may affect any signal path in the equipment and is difficult to shield.

- For the AC power supply system TN, single-phase three-core power socket with protective earthing conductors (PE) should be adopted to effectively filter out interference from the power grid through the filtering circuit.

- The grounding device of the switch must not be used as the grounding device of the electrical equipment or anti-lightning grounding device. In addition, the grounding device of the switch must be deployed far away from the grounding device of the electrical equipment and anti-lightning grounding device.
- Keep the equipment away from high-power radio transmitter, radar transmitting station, and high-frequency large-current device.
- Measures must be taken to shield static electricity.
- Interface cables should be laid inside the equipment room. Outdoor cabling is prohibited, avoiding damages to device signal interfaces caused by over-voltage or over-current of lightning.

2.3 Requirements of Installation Tools

Table 2-4 List of Installation Tools


Common Tools	Phillips screwdriver, flathead screwdriver, related electric cables and optical cables, bolts, diagonal pliers, straps
Special Tools	Anti-static tools
Meters	Multimeter

 The tool kit is customer-supplied.

3 Product Installation

-
- i** Please ensure that you have carefully read Chapter 2.
Make sure that the requirements set forth in Chapter 2 have been met.
-

3.1 Installation Flowchart



3.2 Confirmations before Installation

Before installation, please confirm the following points:

- Whether ventilation requirements are met for the switch
- Whether the requirements of temperature and humidity are met for the switch
- Whether power cables are already laid out and whether the requirements of electrical current are met
- Whether related network adaption lines are already laid out

3.3 Installing the RG-S2910XS-E

Precautions

During installation, note the following points:


- Connect the power cables of different colors to the corresponding grounding posts.
- Ensure that the interface of the power supply cable is well connected to the power interface of the device. The power cables must be protected using power cable retention clips after they are connected to the device.
- Do not place any articles on the RG-S2910XS-E series switch.
- Reserve a spacing of at least 10 cm around the chassis for good ventilation. Do not stack the devices.
- The switch should be located at places free from the large power radio launch pad, radar launch pad, and high-frequency large-current devices. If necessary, electromagnetic shielding should be adopted. For example, use interface cables to shield cables.
- 100-meter network cables should be laid inside the equipment room and outdoor cabling of such cables is prohibited. If outdoor cabling is necessary, take relevant measures for lightning protection.

3.3.1 Mounting the Switch to a Standard 19-inch Rack

The RG-2910XS-E series switches follow the EIA standard dimensions and can be installed in 19-inch distribution cabinets.


Attach the mounting brackets to the switch with the supplied screws, as shown in Figure 3-1.

Figure 3-1 Attaching the Mounting Bracket to the Switch




Align the mounting holes in the mounting bracket with the mounting holes in the rack, as shown in Figure 3-2.

Figure 3-2



Use the supplied M6 screws and cage nuts to securely attach the mounting brackets to the rack, as shown in Figure 3-3.

Figure 3-3




3.3.2 Mounting the Switch on the Wall

The RG-2910XS-E series switch can be mounted on the wall, as shown in the following figure.


Attach the mounting brackets to the switch with the supplied screws, as shown in Figure 3-4.

Figure 3-4 Attaching the Mounting Brackets to the Switch for Wall-Mounting



Use the expansion screws to securely attach the mounting brackets on the wall, as shown in Figure 3-5.


Figure 3-5 Attaching the Switch on the Wall



3.3.3 Mounting the Switch on a Table


Attach the four rubber feet to the recessed areas on the bottom of the switch, as shown in Figure 3-6.

Figure 3-6 Attaching the Rubber Feet to the Recessed Areas



Place the switch on the table, as shown in Figure 3-7.

Figure 3-7 Mounting the Switch on the Table



! The device must be installed and operated in the place that can restrict its movement.


3.3.4 Connecting Power Sharing Cables

The S2910-24GT4XS-PS-E switch supports power sharing among up to 3 devices. The cable-connecting steps are as follows.

Step 1: Remove the dust cap on the Powershare ports to be used.

Step 2: Insert one end of the power sharing cable into a Powershare port and then tighten the screw. There are 0.5/3/10m power sharing cables for choice.

Figure 3-8 Power Sharing Cable



Step 3: If the power sharing combination is composed by two switches, you just need one power sharing cable. Respectively choose one port on both switches to connect the cable as illustrated in Step 2.

Figure 3-9 Connecting Cables between Two Switches



If the power sharing combination is composed by three switches, you need three power sharing cables. Firstly, insert one end of the first cable into a port on Switch A and insert the other end of the cable into a port on Switch B. Then, insert one end of the second cable into the available port on Switch A and the other end into a port on Switch C. Finally, use the third cable to connect the unoccupied ports on Switch B and Switch C.

Figure 3-10 Connecting Cables among Three Switches 1



Figure 3-11 Connecting Cables Among Three Switches 2



Figure 3-12 Connecting Cables Among Three Switches 3



Step 4: Keep the Powershare ports covered by dust caps when these ports are not in use.

3.4 Checking after Installation

⚠ Before checking the installation, switch off the power supply so as to avoid any personal injury or damage to the component due to connection errors.

- Check that the ground line is connected.
- Check that the cables and power input cables are correctly connected.
- Check that all interface cables are laid out inside the equipment room. In the case of external cabling, check that the lightning resistance socket or network interface lightning protector is connected.
- Check that sufficient airflow is available around the device (over 10 cm)


4 System Debugging

4.1 Establishing the Debugging Environment

Establishing the Debugging Environment

Connect the PC to the console port of the switch through the console cable, as shown in Figure 4-1.

Figure 4-1 Schematic Diagram of the Configuration Environment



Connecting the Console Cable

- Step 1: Connect the end of the console cable with DB-9 jack to the serial port of the PC.
- Step 2: Connect the end of the console cable with RJ45 to the console port of the switch.

Setting HeparTerminal Parameters

- Step 1: Start the PC and run the terminal simulation program on the PC, such as Terminal on Windows 3.1 or HyperTerminal on Windows 95/98/NT/2000/XP.
 - Step 2: Set terminal parameters. The parameters are as follows: baud rate 9600, data bit 8, parity check none, stop bit 1, and flow control as none.
1. Choose **Setup>Program>Attachment >Communication> Hyper Terminal**.
 2. Choose **Cancel**, the interface as shown in figure 4-2 is displayed.

Figure 4-2




3. Enter the name of the new connection and click **OK**, the interface as shown in figure 4-3 is displayed. Choose the serial port used currently in the column [use when connecting].

Figure 4-3



4. After choosing the serial port, click **OK** to display the serial port parameter setting interface, set the baud rate to 9600, data bit to 8, parity check to none, stop bit to 1 and flow control to none.

Figure 4-4



5. After setting the parameters, click **OK** to enter the hyper terminal interface.

4.2 Startup Check

4.2.1 Checking before the Device is Powered on

- The switch is fully grounded.
- The power cable is correctly connected.
- The power supply voltage complies with the requirement of the switch.
- The control cable of the PC is properly connected to the console port of the switch. The HyperTerminal is started and the parameter settings are correct.

4.2.2 Checking after Program Startup (Recommended)


After power-on, you are recommended to perform the following checks to ensure the normal operation of follow-up configurations.

- Check whether information is displayed on the terminal interface.
- Check whether the status of the switch indicator is normal.
- Check whether the main program of the device is normally loaded.
- Check whether the time on the device is consistent with the current Beijing time.

- Check whether the service interface forwards data normally.

5 Maintenance and Troubleshooting

5.1 General Troubleshooting Procedure



5.2 Troubleshooting Common Faults

Symptom	Possible Causes	Solution
Forgetting the management interface login password	A password is manually configured but it is forgotten.	Please contact Ruijie Networks Customer Service Department for technical support.
The status indicator is not on after the switch is started.	The power supply module does not supply power. The power cable is in loose contact.	Check whether the power socket at the equipment room is normal and whether the power cable of the switch is in good contact.
The status indicator is red.	Fan alarm Temperature alarm Power alarm	Check whether the fan stops working or is damaged. Temperature alarm: the switch already stops the normal service exchanges. Check in time the working environment of the switch, clean the dust on the cabinet and reinforce the refrigeration effect. Power alarm: the power module problem may be: 1) The power module is in place but no power cord

		is connected. Please power on the module or remove the unused power module. 2) The power module is faulty. Please replace a power module.
The serial port console has no output or outputs illegible characters.	The serial port connected to the switch does not match that opened by the configuration software. The serial port is not configured correctly.	Change the serial port opened by the configuration software to be the one connected to the switch. Check that the parameter configuration of the serial port matches that specified in the instructions.
The RJ45 port is not in connectivity or it is erroneous in receiving/transmitting frames.	The connected twisted pair cable is faulty. The length of the cable exceeds 100 m. The port has special configuration that has no common working mode with the connected switch.	Replace the twisted pair cable. Check that the port configuration has the common working mode with the connected switch.
The fiber port cannot be connected.	The Rx and Tx ends are connected reversely. The interconnected optical module type does not match. The fiber type is not correct. The length of the optical fiber exceeds that rated of the optical module.	Switch the Rx and Tx ends of the optical fiber. Replace the optical module with one of the matched type. Replace the optical fiber with one of the appropriate type. Replace the optical fiber with one of the appropriate length.
The expansion module is not identified by the host.	The module is not properly installed or is in loose contact. The module is installed after the host is powered on.	Power off, install the module, and then power on the host. Power off, remove and install the module again.

Appendix A Connectors and Connection Media


1000BASE-T/100BASE-TX/10BASE-T Ports

The 1000BASE-T/100BASE-TX/10BASE-T is a port that supports adaptation of three rates, and automatic MDI/MDIX Crossover at these three rates.

The 1000BASE-T complies with IEEE 802.3ab, and uses the cable of 100-ohm Category-5 or Supper Category-5 UTP or STP, which can be up to 100 m.

The 1000BASE-T port uses four pairs of wires for transmission, all of which must be connected. Figure A-1 shows the connections of the twisted pairs used by the 1000BASE-T port.

Figure A-1 Four Twisted Pairs of the 1000BASE-T



In addition to the above cables, the 100BASE-TX/10BASE-T can also use 100-ohm Category-3, 4, 5 cables for 10 Mbps, and 100-ohm Category-5 cables for 100 Mbps, both of which can be up to 100 m. Figure A-2 shows the pinouts of the 100BASE-TX/10BASE-T.

Figure A-2 Pinouts of the 100BASE-TX/10BASE-T

Pin	Socket	Plug
1	Input Receive Data+	Output Transmit Data+
2	Input Receive Data-	Output Transmit Data-
3	Output Transmit Data+	Input Receive Data+
6	Output Transmit Data-	Input Receive Data-
4,5,7,8	Not used	Not used

Figure A-3 shows the straight-through and crossover cable connections for the 100BASE-TX/10BASE-T.


Figure A-3 Connections of the Twisted Pairs of the 100BASE-TX/10BASE-T

Straight-Through		Crossover	
Switch	Adapter	Switch	Switch
1 IRD+	1 OTD+	1 IRD+	1 OTD+
2 IRD-	2 OTD-	2 IRD-	2 OTD-
3 OTD+	3 IRD+	3 OTD+	3 IRD+
6 OTD-	6 IRD-	6 OTD-	6 IRD+

Optical Fiber Connection

For the optical fiber ports, select single-mode or multiple-mode optical fibers for connection according to the fiber module connected. The connection schematic diagram is shown in Figure A-4:

Figure A-4 Optical Fiber Connections



Appendix B Mini-GBIC and SFP+ Module

SFP module (Mini-GBIC module) and 10G SFP+ module are available to address the requirements of interface types of switch modules. You can select the Mini-GBIC or SFP+ module to suit your specific needs. Besides the following modules, the 10G SFP+ module also supports the Mini-GBIC-GT module. The models and technical specifications of some Mini-GBIC and 10G SFP+ modules are listed below for your reference. For details, see *Instructions on Mini-GBIC and SFP Series Module* and *Instructions on 10G SFP+ Series Module*.

Table B-1 Models and Technical Specifications of the 100M Mini-GBIC Module

Model	Wave Length (nm)	Media Type	Core Size (um)	Maximum Cabling Distance	DDM (Yes/No)	Intensity of Transmitted Light (dBm)		Intensity of Received Light (dBm)	
						Min	Max	Min	Max
FE-SFP-LX-MM1310	1310	MMF	62.5/125	2km	Yes	-22	-14	-30	-14
FE-SFP-LH15-SM1310	1310	SMF	9/125	15km	Yes	-15	-8	-28	-8

Table B-2 Models and Technical Specifications of the 1000M Mini-GBIC Module

Model	Wave Length (nm)	Media Type	Core Size (um)	Maximum Cabling Distance	DDM (Yes/No)	Intensity of Transmitted Light (dBm)		Intensity of Received Light (dBm)	
						Min	Max	Min	Max
MINI-GBIC-SX-MM850	850	MMF	62.5/125	275m	No	-9.5	-3	-17	0
			50/125	550m					
MINI-GBIC-LX-SM1310	1310	SMF	9/125	10km	No	-9.5	-3	-20	-3
GE-eSFP-SX-MM850	850	MMF	62.5/125	275m	Yes	-9.5	-3	-17	0
GE-eSFP-LX-SM1310			50/125						
GE-eSFP-LX-SM1310	1310		9/125	10km	Yes	-9.5	-3	-20	-3
MINI-GBIC-LH40-SM1310	1310		9/125	40km	Yes	-2	3	-22	-3
MINI-GBIC-ZX50-SM1550	1550	SMF	9/125	50km	Yes	-5	0	-22	-3
MINI-GBIC-ZX80-SM1550	1550	SMF	9/125	80km	Yes	0	4.7	-22	-3
MINI-GBIC-ZX100-SM1550	1550	SMF	9/125	100km	Yes	0	5	-30	-9

i For the optical module with transmission distance exceeding 40 km and more, one on-line optical attenuator should be added on the link to avoid the overload of the optical receiver when short single-mode optical fibers are used.

Table B-3 Specifications of SFP BIDI Optical Module Pairs

Rate/Distance	Module Pairs
100M/20km	FE-SFP-LX20-SM1310-BIDI FE-SFP-LX20-SM1550-BIDI
100M /40km	FE-SFP-LH40-SM1310-BIDI FE-SFP-LH40-SM1550-BIDI
1000M /20km	GE-SFP-LX20-SM1310-BIDI GE-SFP-LX20-SM1550-BIDI
1000M /40km	GE-SFP-LH40-SM1310-BIDI GE-SFP-LH40-SM1550-BIDI



The BIDI modules must be used in pairs (e.g., FE-SFP-LX20-SM1310-BIDI and FE-SFP-LX20-SM1550-BIDI).

Table B-4 Models and Technical Specifications of the Mini-GBIC-GT Module

The existing SFP copper module:

Standard	1000Base-T SFP Type
1000Base-T	Mini-GBIC-GT

The existing 1000Base-T module:

1000baseT	Copper Type	Cabling Distance	DDM (Yes/No)
Mini-GBIC-GT	Category 5 (or above) UTP/STP	100m	No

Table B-5 Models and Technical Specifications of the 10G SFP+ Module


The existing 10G SFP+ optical modules:

Model	Wavelength (nm)	Optical Fiber Type	Core Size (µm)	Modular Bandwidth (MHz·km)	Maximum Cabling distance	Intensity of Transmitted Light (dBm)		Intensity of Received Light (dBm)	
						Min	Max	Min	Max
XG-SFP-SR-MM850	850	MMF (LC interface)	62.5	200	33m	-5	-1	-7.5	0.5
				160	26m				
			50	2000	300m				
				500	82m				
			400	66m					
XG-SFP-LR-SM1310	1310	SMF (LC interface)	9	N/A	10km	-8.2	0.5	-10.3	0.5
XG-SFP-ER-SM1550	1550	SMF (LC interface)	9	N/A	40km	-4.7	4	-11.3	-1
XG-SFP-ZR-SM1550	1550	SMF (LC)	9	N/A	80km	0	4	-24	-7

		interface)							
--	--	------------	--	--	--	--	--	--	--

The existing 10G SFP+ copper modules:

Model	Module Type	Connector Type	Copper Cable Length(m)	Conductor Wire Diameter (AWG)	Data Rate(Gb/s)	DDM (Yes/No)
XG-SFP-CU1M	Passive	SFP+	1	28	10.3125	No
XG-SFP-CU3M	Passive	SFP+	3	28	10.3125	No
XG-SFP-CU5M	Passive	SFP+	5	26	10.3125	No


 For the optical module with transmission distance exceeding 40 km and more, one on-line optical attenuator should be added on the link to avoid the overload of the optical receiver when short single-mode optical fibers are used.

Appendix C Lightning Protection

Installing AC Power Arrester (lightning protection cable row)

The external lightning protection cable row shall be used on the AC power port to prevent the switch from being struck by lightning when the AC power cable is introduced from the outdoor and directly connected to the power port of the switch. The lightning protection cable row is fixed on the cabinet, operating table or the wall in the machine room using the line buttons and screws.

Figure C-1 Schematic Diagram for the Power Arrester



i The power arrester is not provided and the user shall purchase it to address the practical requirement.

Precautions for installation:

- Make sure that the PE terminal of the power arrester has been well-grounded;
- After connecting the switch AC power plug to the socket of the power arrester (lightning protection cable row), lightning protection function implements if the RUN LED is Green and the ALARM LED is OFF.
- If the ALARM LED on the power arrester is Red, you shall check what the reason is, poor grounding connection or the reversed connection of the Null and Live lines: Use the multimeter to check the polarity of the power socket for the arrester when the LED is Red, if the N line is on the left and the L line is on the right, the arrester PE terminal is not grounded; if the L line is on the left and the N line is on the right, the polarity of the arrester power cable shall be reversed; if the LED is still Red, it is confirmed that the arrester PE terminal has not been grounded.

Installing the Ethernet Port Arrester


During the switch usage, the Ethernet port arrester shall be connected to the switch to prevent the switch damage by lightning before the outdoor network cable connects to the switch.

Tools: Cross or straight screwdriver, Multimeter, Diagonal pliers

Installation Steps:

1. Tear one side of the protection paper for the double-sided adhesive tape and paste the tape to the framework of the Ethernet port arrester. Tear the other side of the protection paper for the double-sided adhesive tape and paste the Ethernet port arrester to the switch framework. The paste location for the Ethernet port arrester shall be as close to the grounding terminal of the switch.
2. Based on the distance of the switch grounding terminal, cut the grounding line for the Ethernet port arrester and firmly tighten the grounding line to the grounding terminal of the switch.
3. Use the multimeter to check whether the grounding line for the arrester is in good contact with the switch grounding terminal and the framework.
4. According to the description on the Ethernet Port Arrester Hardware Installation Guide, connect the arrester using the adapter cable (note that the external network cable is connected to the end of IN, while the adapter cable connected to the switch is connected to the end of OUT) and observe whether the LED on the board is normal or not.
5. Use the nylon button to bundle the power cables.

Figure C-2 Schematic Diagram for the Ethernet port Arrester Installation



- i** The Ethernet port arrester is only for the 10M/100M copper Ethernet ports with the RJ-45 connector;
- i** The Ethernet port arrester is not provided, the user can purchase them to address their own practical requirements. For the detailed information during the arrester installation, please refer to Ethernet Port Arrester Hardware Installation Guide, which contains the technical specification and the maintenance and installation of the arrester.

You may pay attention to the following conditions during the actual installation to avoid influencing the performance of the Ethernet port arrester:

- Reversed direction of the arrester installation. You shall connect the external network cable to the “IN” end and connect the switch Ethernet port to the “OUT” end.
- Poor arrester grounding. The length of the grounding line should be as short as possible to ensure that it is in good contact with the switch grounding terminal. Use the multimeter to confirm the contact condition after the grounding.
- Incomplete arrester installation. If there is more than one port connected to the peer device on the switch, it needs to install the arresters on all connection ports for the purpose of the lightning protection.

Appendix D Cabling Recommendations in Installation

When RG-S2910XS-E series switches are installed in standard 19-inch cabinets, the cables are tied in the binding rack on the cabinet by the cabling rack, and top cabling or bottom cabling is adopted according to the actual situation in the equipment room. All cable connectors should be placed at the bottom of the cabinet in an orderly manner instead of outside the cabinet easy to touch. Power cables are routed beside the cabinet, and top cabling or bottom cabling is adopted according to the actual situation in the equipment room, such as the position of the DC power distribution box, AC socket, or lightning protection box.

Requirement for the minimum cable bend radius

- The bend radius of a power cord, communication cable, and flat cable should be greater than five times their respective diameters. The bend radius of these cables that often bend or suffer removal/insertion should be greater than seven times their respective diameters.
- The bend radius of a common coaxial cable should be greater than seven times its diameter. The bend radius of this type of cables that often bend or suffer removal/insertion should be greater than 10 times its diameter.
- The bend radius of a high-speed cable (SFP+ cable, for example) should be greater than five times its diameter. The bend radius of this type of cables that often bend or suffer removal/insertion should be greater than 10 times its diameter.


Requirement for the minimum fiber bend radius

- The diameter of a fiber tray to hold fibers cannot be less than 25 times the diameter of the fiber.
- When moving an optical fiber, the bend radius of the fiber should be equal to or greater than 20 times the diameter of the fiber.
- During cabling of an optical fiber, the bend radius of the fiber should be equal to or greater than 10 times the diameter of the fiber.

Precautions for Bundling up Cables


- Before bundling cables, correctly mark labels and stick the labels to cables where appropriate.
- Cables should be neatly and properly bundled, as shown in Figure D-1.

Figure D-1 Bundling Up Cables (1)




- Cables of different types (such as power cords, signal cables, and grounding cables) should be separated in cabling and bundling. When they are close, crossover cabling can be adopted. In the case of parallel cabling, power cords and signal cables should maintain a space equal to or greater than 30 mm.
- The binding rack and cabling slot inside and outside the cabinet should be smooth, without sharp corners.
- The metal hole traversed by cables should have a smooth and fully rounding surface or an insulated lining.
- Proper buckles should be selected to bundle up cables. It is forbidden to connect two or more buckles to bundle up cables.
- After bundling up cables with buckles, you should cut off the remaining part. The cut should be smooth and trim, without sharp corners, as shown in Figure D-2.

Figure D-2 Bundling Up Cables (2)




- When cables need to bend, you should first bundle them up. However, the buckle cannot be bundled within the bend area. Otherwise, significant stress may be generated in cables, breaking cable cores. As shown in Figure D-3.

Figure D-3 Bundling Up Cables (3)



- Cables not to be assembled or remaining parts of cables should be folded and placed in a proper position of the cabinet or cabling slot. The proper position indicates a position that will not affect device running or cause device damage or cable damage during commissioning.
- The power cords cannot be bundled on the guide rails of moving parts.
- The power cables connecting moving parts such as door grounding wires should be reserved with some access after assembled. When the moving part reaches the installation position, the remaining part should not touch heat sources, sharp corners, or sharp edges. If heat sources cannot be avoided, high-temperature cables should be used.
- When using screw threads to fasten cable terminals, the bolt or screw must be tightly fastened, and anti-loosening measures should be taken, as shown in Figure D-4.

Figure D-4 Cable Fastening



- The hard power cable should be fastened by the terminal connection area to prevent stress.
- Do not use self-tapping screws to fasten terminals.
- Power cables of the same type and in the same cabling direction should be bundled up into cable bunches, with cables in cable bunches clean and straight.
- Binding by using buckles should be performed according to Table D-1.

Cable Bunch Diameter (mm)	Binding Space (mm)
10	80-150
10-30	150-200
30	200-300

- No knot is allowed in cabling or bundling.
- For solder-less terminal blocks (such as air switches) of the cold pressing terminal type, the metal part of the cold pressing terminal should not be exposed outside the terminal block when assembled

Appendix E Site Selection

- The machine room should be at least 5km away from the heavy pollution source such as the smelter, coal mine and thermal power plant, 3.7km away from the medium pollution source such as the chemical industry, rubber industry and electroplating industry, and 2km away from the light pollution source such as the food manufacturer and leather plant. If the pollution source is unavoidable, the machine room should be located on the windward side of the pollution source perennially with advanced protection.
- The machine room should be at least 3.7km away from the sea or salt lake. Otherwise, the machine room must be sealed, with air conditioner installed for temperature control. Saline soil cannot be used for construction. Otherwise, you should select devices with advanced protection against severe environment.
- Do not build the machine room in the proximity of livestock farms. Otherwise, the machine room should be located on the windward side of the pollution source perennially. The previous livestock house or fertilizer warehouse cannot be used as the machine room.
- The machine room should be firm enough to withstand severe weather conditions such as windstorm and heavy rain as well as away from dust. If the dust is unavoidable, keep the door and window away from the pollution source.
- The machine room should be away from the residential area. Otherwise, the machine room should meet the construction standard in terms of noise.
- Make sure the air vent of the machine room is away from the sewage pipe, septic tank, and sewage treatment tank. Keep the machine room under positive pressure to prevent corrosive gas from entering the machine room to corrode components and circuit boards. Keep the machine room away from industrial boiler and heating boiler.
- The machine room had better be on the second floor or above. Otherwise, the machine room floor should be 600mm higher than the highest flood level ever recorded.
- Make sure there are no cracks or holes in the wall and floor. If there are cable entries in the wall or window, take proper sealing measures. Ensure that the wall is flat, wear-resistant, and dust-free, which should be up to the standard for flame retarding, soundproofing, heat absorption, dust reduction, and electromagnetic shielding.
- Keep the door and the window closed to make the machine room sealed.
- The steel door is recommended for soundproofing.
- Sulfur-containing materials are forbidden.
- Pay attention to the location of the air conditioner. Keep the air conditioner from blowing wind straight toward the device or blowing water drops from the window or air vent toward the device.